


EC52
with
Munters Drive

Manual for use and maintenance



+ CE Declaration of conformity

EC52 with Munters Drive

Air extraction fan

EC52 with Munters Drive

Manual for use and maintenance

Original instructions

Revision 1.2

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation and has been produced with reference to Directive 2006/42/EC, paragraph A, Annex II, and to ErP Directive 2009/125/CE Commission Regulation 327/2011.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorisation of the assembler of the system.

Munters Italy S.p.A. reserves the right to effect modifications to the apparatus in accordance with technical and legal developments and to make alterations to specifications, quantities, etc., for production or other reasons, subsequent to publication.

Warranty

For Warranty information please refers to "General terms and condition of sale" available on https://www.munters.com/globalassets/terms-and-policies/condizioni_generali_vendita.pdf

Conditions and Limitations:

- Products and Systems involved in a warranty claim under the "General terms and condition of sale" shall have been properly installed, maintained and operated under competent supervision, according to the instructions provided by Munters;
- Malfunction or failure resulting from misuse, abuse, negligence, alteration, accident or lack of proper installation or maintenance shall not be considered a defect under the Warranty.



CONTENTS

1. CE DECLARATION	4
1.1 Disclaimer	5
1.2 Introduction	5
1.3 Notes	5
1.4 Data for Fan Eco Design Directive	6
1.5 Attached technical documentation	6
1.6 Disposal	6
2. SAFETY ASPECTS	7
2.1 Personnel requirements	7
2.2 General safety instructions	8
2.3 Safety devices	8
2.4 Residual risks	10
3. BEFORE USING	12
3.1 Delivery check	12
3.2 Packaging and transport of assembled fans	12
3.3 Structure	13
4. OPERATING CONDITIONS	14
4.1 Intended conditions of use	14
4.2 Non-permitted conditions of use	14
5. INSTALLATION	16
5.1 Choice of site and checking installation requirements	16
5.2 Assembly of the cone	17
5.3 Placement of fans	19
5.4 Electrical wiring	20
5.5 Standard wiring between VFD and motor	26
6. COMMISSIONING	27
6.1 Control devices	27
6.2 Instructions for starting up	27
7. TECHNICAL DATA	29
7.1 Dimensions	29
7.2 Technical specifications	29
7.3 Recommendation for use	30
8. MAINTENANCE	31
8.1 Introduction	31
8.2 Cleaning	31
9. SPARE PART LIST	32
EC52 with Munters Drive	32
Spare parts	34

1. CE DECLARATION

CE DECLARATION OF CONFORMITY

(complies with Subparagraph A Annex II Directive 2006/42/EC)

Munters Italy S.p.A.

with registered offices in Strada Piani, 2 – 18027 Chiusavecchia (IM) – Italy
(Company Registration nr. 00081050080)

declares on its own responsibility that the apparatus:

Designation	Fan designed for moving air to control temperature and humidity in greenhouses or rearing sheds.
Model	EC52 with Munters Drive
Year of manufacture	2016

CONFORMS WITH THE ESSENTIAL SAFETY REQUIREMENTS STATED
BY APPARATUS DIRECTIVE 2006/42/EC AND PERFORMANCE
REQUIREMENTS
COMPLY WITH THE ERP DIRECTIVE 2009/125/CE.

with particular reference to the following provisions:

UNI EN 953:2009, UNI EN ISO 12100:2010, UNI EN ISO 12499:2009,
UNI EN ISO 13857:2008, CEI EN 60204-1:2006 (CEI 44-5), UNI EN ISO
5801:2009

Chiusavecchia, 7th January 2020
Massimo Colombo



Legal Representative

1.1 Disclaimer

Munters reserves the right to make alternations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing a Munters fan!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the fan, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters fans.

1.3 Notes

Date of release: 2016.

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

1.4 Data for Fan Eco Design Directive

Product information requirements → (according to ANNEX I -3.2 of regulation)	1	2	3	4	optional	5	6a	6b	6c	7	8
Fan description ⁽¹⁾	Overall efficiency $\eta\%$	Measurement category	Efficiency category	Efficiency grade	Target efficiency grade 2015	VSD must be installed with the fan	Motor power input at optimum energy efficiency [W]	Flow rate at optimum energy efficiency [m ³ /h]	Pressure at optimum energy efficiency [Pa]	RPM at optimum energy efficiency	Specific ratio
EC52 with Munters Drive	40,9	A	static	45,5	40	yes	1.926	33441	79,5	495	1

* Fans tested are configured according to COMMISSION REGULATION (EU) No 327/2011 of 30th March 2011 - ANNEX II - 1.5. Efficiency values, according to Commission Regulation (EU) 327/2011, refers to exhaust fans only.

1.5 Attached technical documentation

The listed documentation is to be considered an integral part of this manual:

- gear motor instruction booklet.

1.6 Disposal

Do not dispose of this product with general household waste. This product must be disposed according to the laws governing Waste Electrical and Electronic Equipment. If required, contact your local authorities for information regarding the available disposal facilities.

2. SAFETY ASPECTS



WARNING Failure to respect safety or behavioral rules can produce hazardous situations for users as well as damage to the machine and the place where it is installed. The fan must only be used if it is in perfect operating condition, by personnel who are perfectly aware of the safety measures and possible hazards, and in strict compliance with the instructions given in this manual.

2.1 Personnel requirements

Equipment may only be used by personnel who know and apply the specific requirements given in the user and maintenance manual and the more general instructions contained in various regulations for accident prevention and applicable legislation regarding safety in the workplace, as well as other European Community directives incorporated by the member states into their national legislation.

Knowledge and understanding of the manual and of the attached documents constitute an indispensable tool for reducing hazards and promoting the safety and health of workers.

Personnel training

All operators engaged in the use of the fan must have received adequate information from the employer relating to:

- risks to health and safety at work connected with the use of the machine;
- first aid procedures, fire precautions and evacuation of workplaces;
- devices provided for the safety of operators, and residual risks generated by the machine.

In particular, the employer has the following duties:

- when assigning tasks to operators, to take into account their capabilities in the interests of safeguarding their health and safety;
- to provide adequate means of protection;
- to require compliance by individual operators with the company rules and provisions regarding safety and the use of the collective and individual protective measures at their disposal;
- to ensure that normal and special maintenance operations, or in any event operations necessary for machine safety, are regularly carried out.

All operators must take care of their own safety and health as well as that of other people in the workplace who may be affected by their actions or omissions, in accordance with their personal skills, and the instructions and means provided to them by the employer.



WARNING Unauthorized tampering/replacement of one or more parts of the machine, or the use of accessories, tools or materials other than those recommended by the manufacturer, are prohibited and release the manufacturer from all liability.



WARNING Operators must be trained to deal with the occurrence of possible faults, malfunctions or dangerous conditions to themselves or others, and in such an event must:

- stop the fan immediately by operating the emergency stop device (mushroom-shaped pushbutton/main switch mounted on the electrical panel);
- not carry out operations which are beyond their duties and/or technical knowledge.

2.2 General safety instructions



WARNING

- Safety devices must not be removed or rendered ineffective;
- the fan must not be started with guards removed;
- any adjustment or maintenance operation must be performed with the electrical isolating device activated and locked in position with a padlock;
- any operation is prohibited which may cause arcing or sparks or other situations which could start a fire;
- in the event of alarm signals resulting in the intervention of safety devices, the operator must ask for immediate action by qualified technicians responsible for maintenance;
- user must ensure that the environmental and electricity supply conditions in which the fan operates are always within the limits specified in this user manual;
- do not for any reason modify parts of the fan in order to fit additional devices.

2.3 Safety devices

In the process of designing and building the fan, the manufacturer adopted the necessary technical solutions to ensure compliance with fundamental safety requirements: the object of the risk reduction process was to ensure that the operator can use the fan in safety. The machine is provided with protection devices of fixed type and is fitted with an actuator for the emergency stop function.

Fixed guards

The fixed guards are solidly fixed to the structure of the machine and cannot easily be eluded: the guards are fixed with systems which require the use of tools for dismantling.



WARNING Do not start the fan with fixed guards removed: the guards can only be removed with special tools, by specialized and trained personnel and with the system stationary (emergency system activated and electricity and hydraulic fluid isolated).

At the end of maintenance operations, the guards which were removed must be replaced correctly.

Position of guard	Type of guard	Notes
Intake side of fan	Guard of fixed type made of metal mesh.	Dimensions and positioning in accordance with the instructions in the standard UNI EN 13857. Removable only by means of special tool.




fig.1

Outlet side of fan	Guard of fixed type made of metal mesh.	Dimensions and positioning in accordance with the instructions in the standard UNI EN 13857. Removable only by means of special tool.
--------------------	---	---




fig.2

Emergency stop function







fig.3


The machine must be equipped at the installation stage with an electrical panel, on which must be installed an actuator for the emergency stop function, which when operated brings dangerous movements to a halt by isolation of the power supply: the button must be mushroom-shaped and coloured red, provided with mechanical restraint and released by turning.

2.4 Residual risks

Hazards generated by noise (<i>measured at 2m distance</i>)	
Fan model	Sound pressure level Lp [dB(A)]
EC52 with Munters Drive	77

A measurement has been made of the noise produced by the machine during normal operation in order to calculate the equivalent level in conditions of normal use. These values are shown in the above table.

Mechanical hazards		
Part of machine / stage of use	Description	Plates / provisions / PPE
Installation of machine	Hazard arising from failure to observe ergonomic principles, caused by excessive strain, i.e. generic mechanical hazard during the moving and installing stages of the machine.	<div></div> <p>fig.4</p>

Electrical hazards		
System area	Description	Plates/provisions/PPE
Panels, covers and electrical apparatus.	The safety signs must be fixed in an extremely visible position on the door of the electrical panel and on covers containing electrical apparatus, to highlight the risks to which an operator could be exposed in the event of opening the electrical panel (danger resulting from the presence of live parts), the level of voltage present, the prohibition of tampering by unauthorized personnel and the prohibition on the use of liquids on electrical apparatus in the event of fire.	 fig.5



WARNING The user and the employer must comply with current national law in terms of protection against daily personal exposure of operators to noise, by providing the use of personal protective equipment (earmuffs, earplugs, etc.) if necessary, depending on the overall level of sound pressure in the installation area, and the daily personal exposure of the employees. In areas where the overall sound level reaches excessive values, personal protective equipment must be used.



WARNING The fan must only be used if it is in perfect operating condition, by personnel, aged more than 14 years who are perfectly aware of the safety measures and possible hazards, and in strict compliance with the instructions given in this manual.

3. BEFORE USING



3.1 Delivery check


Upon receipt, inspect the fan for external damage and if found, inform the forwarding agent without delay. Check the data on all the rating plates, especially voltage and frequency. Turn the propeller by hand while the fan is switched off to verify smooth rotation of the propeller.

3.2 Packaging and transport of assembled fans

The fan has a self-supporting structure in galvanised steel and it is usually delivered in cardboard boxes.

Before starting the mounting procedure of the fan, check the opening of the shutter blades manually unlocking the actuator by using the magnetic tool. After the check reset the magnetic tool in working position.





Fans should not be permanently stocked one upon the other, regardless if they are delivered with or without packaging. Handling of the fans should not be done manually as the fans have no handles or grips. Consequently, one of the following alternatives should be used:

- forklift: before loading, make sure the forks are opened as much as possible to avoid bending of the fan bottom panel;
- crane: fix two bolts in the M8 bushes situated on the sides of the fan housing and hook the lifting cable over the bolts.



WARNING Make sure a steel cable or rope of adequate size is being used when the fan is lifted by crane. Fan weights are shown in the technical specification table (see section 7.2).

3.3 Structure

The fans consist of the following components:

- fan housing in Munters Protect coated steel without welding spots;
- fan shutter in Munters Protect coated steel, which pivots on UV protected plastic bushes and pins;
- propeller with four blades in stainless or Munters Protect coated steel; blades are fixed to the propeller by high-strength pop rivets;
- Meshes for protection on back and front side;
- Munters Drive Motor: EC motor plus inverter (VFD).

4. OPERATING CONDITIONS

4.1 Intended conditions of use

Exhaust fans are machines designed for moving air to control temperature and humidity in greenhouses or rearing sheds by extraction, not under pressure.

Normal ambient temperature limits are -15°C to +40°C. Maximum altitude is 1000m above sea level. Should a fan be required to operate at a higher altitude, the loss in mass flow (heat removing capacity) due to lower air density should be taken into consideration.

The fan has been designed and built to operate in safety for the user, if used according to the conditions intended by the manufacturer and stated in this user and maintenance manual.

4.2 Non-permitted conditions of use

Total or partial failure to observe the instructions given in this manual could cause damage to the fan and/or people.

The following uses are to be considered not permitted and improper:

- use in the event of faults and/or tampering with the installed safety devices;
- use by personnel not specifically trained;
- installation of the fan for extraction or circulation under pressure;
- use contrary to existing regulations;
- incorrect installation differing from instructions given in this manual;
- supply from an electrical network with characteristics different from that specified in the wiring diagram;
- total or partial failure to observe instructions;
- insufficient maintenance;
- use of non-original spare parts;
- use of lubricants with characteristics different from those specified in the technical documentation attached to the manual;
- use by minors;
- use under the influence of drugs, alcohol, etc.



WARNING Use of the fan other than as described in the user manual or outside the operational limits laid down by the manufacturer is considered IMPROPER USE. In the event of IMPROPER USE the manufacturer declines all liability in relation to any damage that may be caused to persons or property, and any kind of warranty will be considered invalidated.

Use of non-original spare parts

Original spare parts ensure the reliability and safety of the operation of the fan: in the event of maintenance/replacement, consult the spare parts list, the list of parts and components used and the relevant technical documentation attached to this manual.



WARNING In the event of replacement of safety devices, it is essential to maintain the safety and operational characteristics of the original device, preferring replacement with an identical component.

Insufficient maintenance

A correct normal maintenance is one that maintains the original integrity or restores the fan's efficiency, while at the same time limiting normal deterioration resulting from use.

Special maintenance work can also prolong the usable life of the machine and/or, secondarily, can improve its efficiency, reliability, productivity and ease of maintenance and inspection.

Unauthorized modifications or tampering

No operation is permitted which is aimed at making modifications to the fan and the safety devices fitted to it; similarly, it is not possible to alter its operational and performance characteristics.



WARNING Interference with the command and control circuits is prohibited: such operations could cause damage to the equipment and serious danger to the operator.



NOTE Modifications made to the fan which do not come into the categories of normal and special maintenance, or which alter its operational and performance characteristics, invalidate the machine's compliance with the requirements of the applicable directives, as attested by the manufacturer with the EC declaration of conformity: it is up to the person responsible for the modification to resubmit the machine to the assessment conformity procedures specified in the applicable directives.

Use in a potentially explosive atmosphere

The fan has been designed and built to operate in environments where the presence of a potentially explosive atmosphere is not expected, in other words it is not intended to handle materials which release explosive dust. Emission into the atmosphere of harmful particles or gases must be contained within the limits established by current regulations.



WARNING The fan has been designed and built in such a way that it CANNOT operate in a classified area, according to directive 1999/92/EC.



WARNING The metal sheets used for constructing the fan housing and shutter blades have a surface coating made of an alloy of Zinc, Aluminum and Magnesium, classified as Zm120 (equivalent to 9 µm of coating thickness on each side of the panels) which corresponds to a corrosion resistance in salty mist of 1800 hours.

Whenever it is intended to use the fans in ambients characterized by the presence of particularly aggressive agents (ammonia, clavulanic acid, etc.) the user, before installing the fan at the installation site must verify that the environmental conditions are compatible with the intended use of the materials that compose the fan.

5. INSTALLATION

After fan has been delivered but before fitting and installation, check condition of the consignment: in the event of discrepancy or damage to the machine, the manufacturer or carrier must be informed immediately.



WARNING Fitting and installation of the fan must be performed by specialized personnel, in order to prevent damage to the equipment or hazards to people as a result of faulty fitting.

Fitting the fan must be carried out according to the following stages:

- positioning and anchoring the fan;
- connection to the mains electricity supply;
- operational testing and putting into operation.

5.1 Choice of site and checking installation requirements

The user is responsible for preparing an area suitable for installation of the equipment and complying with the requirements laid down by European directives and national law governing safety at places of work. Environmental conditions for operating the equipment are as follows:


Ambient temperature during operation	Ambient humidity during operation
-15°C / +40°C	< 90%

For operation of fan installation, a manoeuvring area must be made available that is suitable for the fan dimensions and the chosen lifting equipment: electrical points must be provided in the installation area for fan connection to the mains electricity supply.

Irrespective of the place of installation, suitable indelible warning signs are attached to the fan, warning of danger and giving instructions to remain at a safe distance not to place hands inside the shutter and not to run in proximity of the fan.


The warning signs are yellow, self-adhesive and indelible. They are fitted to the front and rear of the fan, and marked with the numbers A-1997 and B-1997 (see fig.10).

The area adjacent to the fan in the premises from which air is being extracted must be kept clear to allow the air to exit freely. It is also prohibited for anyone to remain in this area, because of the presence of organic gases and dust which may be present in the airflow.



5.2 Assembly of the cone

Fans are delivered with the cone disassembled to minimise space usage during transportation. To move the cone to its working position, it is necessary to follow the steps indicated below.






fig.13

4. Repeat from step 2, using the remaining two sectors, steering the fingers on the same side.
5. Close the cone steering the fingers internally.




fig.14

6. Fix the cone sectors together by using 1 screw, 2 washers and 1 nut. Repeat the operation 8 times.




fig.15

7. Place the round mesh on the discharge cone.





fig.16


8. Bolt all the grommet to the cone by using 1 screw, 2 washers and 1 nut.




5.3 Placement of fans



WARNING There must be no obstacle neither in front or behind the fans. The outgoing airflow must be kept free at least of a length of 3-times fan diameter and the ingoing airflow must be kept free at least in a radius of 1.5 m distance in front of the fan.



WARNING Fans have to be installed taking care to have central support placed in correspondence of a concrete wall or a dedicated metal frame, which has to be strong enough to support the weight of the fan. This is mandatory for guaranteeing the correct functioning of the fans eliminating vibrations and avoiding possible malfunctioning.



WARNING In order to comply with CE regulations, fans should be mounted so that the bottom of the fan is 2.7m or higher from the floor below it. If the fan is to be installed at a lower height it should be equipped with special safety meshes which are available as an optional extra.

Failure to install the safety mesh releases the manufacturer from all liability and shall be considered an improper use of the machine.

5.4 Electrical wiring




The fan is delivered with inverter (VFD) and motor wired but the gear motor has to be mounted and installed as shown in the following schemes. Once installed the fan needs 2 lines of power supply (400Vac triphase for the motor and 230Vac single phase for the gear motor). A 0-10Vdc signal line is requested for speed adjusting.

Power supplies and signal must be wired as follows. For safety reason and regulations compliance, connection to the power supply must be done by mean of the following devices:



fig.20

Lockable isolating switch.

 <p>fig.21</p>	<p>Magnetothermal switch (chosen to suit the power of the motor).</p> <p>The need to fit a switch of differential type depends on the configuration of the electrical system supplying the fan: it is the installer's responsibility to make this assessment in accordance with the instructions in standard IEC 60364.</p>
 <p>fig.22</p>	<p>Red emergency stop button, mushroom type, provided with mechanical locking and release by turning (in compliance with UNI EN ISO 13850). Operating the button must bring about the electromechanical isolation of the power supply to the electric motor (category 0/1 according to IEC EN 60204-1).</p>
 <p>fig. 24</p>	<p>Start/stop selector switch (with characteristics compatible with the nominal current of the motor), or main panel for managing the equipment, with control devices which act on the electrical supply to the fan.</p>




WARNING Do not supply power to the fan during installation stage.


Installer must issue a declaration of correct installation in accordance with applicable legislation in the country of use.

For further information about markings and warning signals of VFD, please refer to the Yaskawa manual. These devices are not supplied by Munters.

A network filter (type FIN3755.007.M), compulsory to comply with European EMC requirements and supplied by Munters upon request in a dedicate box, is also needed and must be wired upstream of the VFD. Moreover, a toroid, is already wired by Munters on the line between VFD and motor.



Below are suggested wiring diagrams. These diagrams are however subject to local laws and regulations and should be modified if necessary to comply with such laws and regulations.



To operate the Munters Drive Off/Variable speed with a 0-10V signal, slide the 'ON' switch, located on the circuit board in the VFD, away from the 'ON' position. Connect wires from the '0-10V IN' and '0-10V COMMON' terminals in the VFD to the 0-10V output in the control.

The Munters Drive motor consists of different elements which interact for obtaining a smooth and reliable working: the permanent magnet motor, the VFD, the gear motor for shutter opening, the network filter (supplied on request).

Here a sequence of the connections and the working sequence of the EC52 with Munters Drive:

Electrical connections

VFD have to be connected to a 3 phase powers supply. The line has to be protected by a overload switch dimensioned to guarantee the safe operation of the machine.

A double dry contact from the controller has to be connected to the VFD and to the Belimo (see fig.25).

A 0-10 Volts signal has to be connected as input to VFD for regulating the speed of propeller of the fan. 10 Volts is the max speed, while 0 volts is the minimum speed.

Operation sequence

Normally the shutters of the fans are closed. When the logic of controller decides to start the fan, then the relay of controller closes. In this way the gear motor will start to rotate for opening the shutter blades. At the same time the other contact will close and, consequently, the propeller will start to spin. The spinning speed is determined by the value of the 0-10 Volts applied by the controller.

When there is the need to stop the fan, the controller will open the 2 contacts by deactivating the dedicated relay. The gear motor will start to close the shutter. The Munters Drive will start its stopping process. The gear motor will continue to rotate till the shutter will be completely closed. There is no need to remove the power from the gear motor when the shutter reaches its full closing since the gear motor is designed for operating with power supply constantly connected.



NOTE Failure to operate the fan with an overload protection device will render the motor guarantee null and void. Such motor overload protection devices can be ordered from Munters and be supplied with the fans.



NOTE The excess of length of the connection cable must be completely extracted from the fan housing in order to avoid being damaged by moving parts.

To avoid excessive voltage drop, which can be harmful to electrical motors, care must be taken as to the thickness of cables used as well as the distance (D) from the main electrical enclosure to the motor. In the Table below are the maximum allowable distances.

Cross sectional area of cable		
1.5 mm ²	2.5 mm ²	4 mm ²
Maximum allowable length: D [m]		
90	150	240

Standard fan motors have the following voltage and frequency:
400V three-phase 50 Hz.




fig.26

Motor specifications are written on the label stuck on the frame and motor (no. 1 and 2 in diagram).



WARNING In the event of installations that do not comply with the directions given in this chapter, the manufacturer's liability ceases, along with the validity of the CE Declaration of Conformity.



WARNING In case of line failure we recommend to set up in the controller with a shutdown cycle and restart cycle.

The electrical lines must be laid in accordance with requirements of the laws applying in the place of installation, and in any event:

- they must be laid with cables of adequate section for the power of the fan and the length of the line itself;
- they must make an effective earth connection;
- they must have isolating devices and automatic protection against overload and short circuits.

Before activating the electrical supply to the machine by turning the isolator switch to position On, a series of checks must be made:

- check that the voltage and frequency of the power source correspond to those indicated in the equipment technical data and electrical diagram;
- check that the supply cables and the conductor providing external protection are correctly connected;
- check that the connections in the control and power circuits are properly tight;
- check that the intensity of the short-circuit expected at the connection terminals is compatible with the breaking power of the protection switch upstream of the electrical panel;

- check that the protection devices (fuses, magnetothermic switches) are correctly sized, and that the phases are connected in the correct order: check that the fan rotates in the right direction.

Equipotential earthing wiring safeguard

To create effective protection against the risk of electrocution, the outer protection conductor must be connected to terminal PE inside an electrical panel.

For correct sizing of the protection conductors, see following requirements as indicated in standard IEC EN 60204-1:

- phase conductor up to 16 mm²: section of the protection conductor equal to the section of the supply conductor;
- phase conductor between 16 and 35 mm²: section of protection conductor equal to 16 mm²;
- phase conductor over 35 mm²: section of protection conductor equal to at least half the section of the supply conductor.



WARNING When connecting all the metal masses to the earth system, check that there are no insulating elements between the various conductive masses (metal parts). The system must not be put into operation unless the equipotentiality of the masses and the connection to the earth system have previously been checked.

Protection against contact voltages

The choice of device to protect the electrical system must be made in such a way as to ensure the safe intervention of the main automatic switches and any differential devices linked to them. For an appropriate choice of the type of protection for the machine's supply line, taking into account whether the distribution system is TT or TN, it is advisable to consult an electrical systems designer, in order to ensure compliance with the requirements of standard IEC 64-8 or the equivalent provisions in the country where the machine is being installed.

5.5 Tests and checks before startup

Before startup, it is extremely important to carry out a very careful check of the fan, in order to prevent malfunctions and/or accidents.

In particular, perform the following operations:

1. Equipotential earthing wiring safeguard:
 - check the fan visually, verifying that there are no particular mechanical irregularities or foreign bodies inside the structure;
 - check that the protective structures (fixed guards made of metal mesh) are correctly positioned and fixed;
 - check that the emergency stop function actuator operates correctly.
2. Checking the electrical system:
 - check that the supply conductors are properly fixed to the terminals of the isolating switch;
 - check the connections of the conductors in the equipotential earthing wiring safeguard;

- check that the guards inside the electrical panel are correctly positioned and fixed;
- check that the safety devices are receiving power and are active, and check their effectiveness.

After this series of checks has been carried out, the fan is ready for its first startup.



WARNING It is necessary that the resistance of the ground line to which the equipment are connected has a very low values (about 15-20 ohm) in order to avoid high currents that can flow through the motor bearings and damage them.

It is necessary to install the proper line filters, to avoid interference and allow proper operation of the equipment.

5.6 Standard wiring between VFD and motor

Motor and VFD are already wired by Munters. If, for some reason, wiring is unplugged follow the schemes.

Power Terminal Block (line, VFD, Motor):

R,S,T for input 3 phase

U,V,W for the output to the motor

Control Circuit Terminal Block (VFD):

Common - black - SC

Run - red - S1

Reduced flow - white - S7

0-10V in - blue - A1

0-10V common - green - AC

Alarm - purple - MB


Alarm common - grey - MC

Option - yellow - MP

Option common - orange - AC

Pot - brown - +V

Shortcut bridge - black - between HC and H1



6. COMMISSIONING



WARNING The fan must not be used without first reading and understanding the user manual and becoming completely familiar with the controls.

6.1 Control devices

This chapter gives instructions on the control devices with which the electrical control panel must be fitted, which shall be done at the installation stage.

At the fitting stage, the installer must set up a control panel complying with the requirements of standard IEC EN 60439-1 and arrange the wiring of the fan in accordance with the instructions in standards IEC EN 60204-1 and IEC 60364.

The electrical circuit of the fan must generally be fitted with the devices indicated in section 5.4.

6.2 Instructions for starting up

Before starting the machine:

- check that all the guards for the hazardous areas are in their correct positions;
- check that all the electrical safety components are in place and check their effectiveness by activating them;
- check the presence of the electricity supply.

To start the fan, go through the following procedure:

- turn the isolator switch to position On;
- press the fan starter button.

Normal stopping

In the event of necessity the fan can be stopped by operating the relative control device (stop), which shall be installed on the electrical panel.

Activating this control must cause the fan blade to stop rotating, but does not cause isolation of the power supply: the fan can be started again by pressing the start button.

In the event that the fan does not need to be used for an extended period of time the following stop procedure must be used:

- operate the stop button
- operate the emergency stop button;
- open the main isolator switch (position "0") on the electrical panel and attach a padlock to the actuator.



WARNING Interrupting the electricity supply, equivalent to isolating by the operator with the main switch, causes complete fan shutdown: restoring the electricity supply will not cause any movement in the machine.

Emergency stop

Operating the main emergency stop button causes the fan to stop moving.

The function is controlled by a red mushroom type button on a yellow background, provided with mechanical locking and release by turning. Operating it causes the instantaneous interruption of the power supply to the electric motor which makes the rotor turn (uncontrolled shutdown category 0 according to IEC EN 60204-1).

Resetting after stopping


1. Resetting after normal stopping
After normal stopping the operating cycle must be reset by following the procedure described in section 6.1.
2. Resetting after emergency stop
After an emergency stop, the operating cycle must be reset by following the procedure described below:
 - reset the actuator by which the emergency stop command was given (by turning the relative mushroom button);
 - for an exact reset sequence, refer to the instructions given in section 6.2.



WARNING Do not attempt to correct any problem observed during the above mentioned steps while the fan is in operation. Wait until the electrical power has been switched off and the fan has come to a complete stand still. Lock the electrical switch in the off position with a pad lock while working on the fan.

7. TECHNICAL DATA

7.1 Dimensions

Dimensions [mm]								
 <p>The image contains two technical drawings of a square axial fan. The left drawing is a front view showing the propeller and grille, with dimensions A (height), B (width), C (grille height), and D (grille width). The right drawing is a side view showing the motor and housing, with dimensions E (motor width), F (motor depth), G (total depth), and H (motor height). A small detail 'I' points to a mounting hole on the side view.</p>								
A	B	C	D	E	F	G	H	I
1,425	1,425	1,500	1,500	90	450	735	295	M8

7.2 Technical specifications

Technical specifications				
		260 rpm	370 rpm	485 rpm
Number of blades		4		
Propeller diameter	mm [inch]	1,335 [52]		
Weight of fully equipped fan*	[kg]	120		
Airflow at 0 Pa	m ³ /h [cfm]	28,500 [16,800]	40,700 [24,000]	53,200 [31,300]
Airflow at 12 Pa	m ³ /h [cfm]	24,300 [14,300]	37,700 [22,200]	51,400 [30,200]
Airflow at 25 Pa	m ³ /h [cfm]	15,200 [8,900]	34,600 [20,400]	49,400 [29,100]
Specific performance at 12 Pa**	m ³ /h/W [cfm/W]	81.2 [47.8]	49.9 [29.4]	30.6 [18.0]
Specific performance at 25 Pa**	m ³ /h/W [cfm/W]	48.0 [28.3]	43.8 [25.8]	28.4 [16.7]

Max. operating temperature	°C [°F]	40 [104]
Max. operating pressure	[Pa]	50
Electric motor winding insulation grade		B


* Includes safety kit for installation below 2.7m above the floor.

** All declared values are measured and certified by Bess Lab (test #16701). Airflow data are measured at standard conditions (20°C, 1,013 hPa).

7.3 Recommendation for use

Pressure	[Pa]	13	20	25	30	40	50
Speed	[rpm]	200	260	300	300	33	410
Airflow	[m³/h]	13500	19400	22800	20500	20500	30900
Power	[W]	152	310	450	448	581	1096

Munters Drive - Control Voltage



8. MAINTENANCE

8.1 Introduction

Maintenance must only be carried out by qualified personnel only using suitable tools and working methods. It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer. The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Before any maintenance steps are taken, make sure the power switch is in the off position and locked by a padlock. Make sure the propeller is at a complete standstill.

Fans do not contain parts needing periodic lubrication, as moving parts are either manufactured from self lubricating materials, or are sealed with lifetime lubrication.

8.2 Cleaning

Inspect the fan at regular intervals and keep it clean. It is advised to perform periodic cleaning of safety mesh guards. Dust on the safety mesh guards causes extra power consumption; severe dust on the motor can cause overheating and subsequent motor failure.



WARNING Keep motor body clean. Dust deposit on motor body will lead to overheating and failure of bearings and motor itself.

Do not use water for motor cleaning. Use compressed air only. Water spraying will cause rust inside the bearings and lead to their failure.



WARNING Even if the components are water resistant we recommend to avoid to use high pressure water to clean the system.




WARNING All the components and spare parts **MUST** be stored in dry and clean environment.




WARNING Do not operate the fan with the safety protections removed: safety meshes can be removed only with specific tools by qualified technicians when the fan reaches a complete standstill. Safety protection are placed on both inlet and outlet part of the fans and the purpose is to avoid to reach rotating and moving components. The fixing systems of the safety protections are not interchangeable with other devices. Therefore, if for maintenance reasons the user damages or loses any component, this must be definitely ordered from the manufacturer as spare parts and it cannot just be replaced with other components, even similar, not supplied by the manufacturer itself. In this particular event the manufacturer refuses all responsibility on consequent damages caused to things and people and considers any kind of warranty lost.

9. SPARE PART LIST


EC52 with Munters Drive




DETAIL B




DETAIL C



DETAIL D: BELIMO ACTUATOR



ELECTRICAL BOX (OPTIONAL)



Spare parts

REF.	DESCRIPTION	QUANTITY
1	ROUND CONE SAFETY MESH	1
2	CONE SECTOR	4
3	Ø6.4x8 POP UP RIVET	28
4	SIDE PANEL	2
5	TOP PANEL	1
6	THREADED BUSH M08x17.5	8
7	RUBBER FOR CABLE	2
8	COVER PLATE	2
9	CENTRAL SUPPORT	1
10	PLASTIC TIE ROD	2
11	D10x40 PLAIN WASHER	2
12	COMPLETE RIGHT BEARING	10
13	SHUTTER BLADE	9
14	SHUTTER BLADE FOR BELIMO SLIM	1
15	COMPLETE LEFT BEARING	9
16	METAL CLIP FOR MESH	10
17	PYRAMIDAL SAFETY MESH	1
18	Ø6,3x19 SELF-TAPPING SCREW	19
19	MUNTERS DRIVE MOTOR	1
20	M10 HEX NUT	4
21	EXT TOOTHED WASHER D10,5X18	4
22	PLASTIC OVAL PLATE	2

23	M10x30 SCREW	4
24	PROPELLER	1
25	BOTTOM PANEL	1
26	CONVEYOR	1
27	CONE BRACKET	4
28	M06 HEX NUT THICK	28
29	Ø6 SPRING WASHER	12
30	M06X16 HEX SCREW	28
31	Ø6x24 WASHER	40
32	PLASTIC PIN FOR BELIMO CM	1
33	BELIMO ACTUATOR	1
34	PLASTIC SX BEARING FOR SMT SLIM	1
35	Ø5 SPRING WASHE	4
36	M04 HEX NUT THICK	4
37	3 PHASE FILTER	1
38	GEWISS BOX GW44428	1
39	SELF TAPPING SCREW	4
40	M04x16 HEX SCREW	4
41	PLATE FOR ELECTRIC BOX	1
42	PG11 GLAND	2

Requests for technical assistance and spare parts must be made directly to the manufacturer, at the following address:

Munters Italy S.p.A

Strada Piani, 2

18027 Chiusavecchia (IM), Italy

Tel: +39 0183 52 11

Fax: +39 0183 521 333

info@munters.it

Munters EC52 with Munters Drive extraction fan is developed and produced by Munters Italy S.p.A., Italy



[Australia](#) Phone 61 2 8843 1594, agh.info@munters.com.au, [Brazil](#) Phone +55 41 3317 5050, contato@munters.com, [Canada](#) Phone +1 517 676 7070, aghort.info@munters.com, [China](#) Phone +86 10 8048 3493, marketing@munters.cn, [Denmark](#) Phone +45 98 623 311, aghort@munters.dk, [Germany](#) +49 (0) 25 58 - 93 92-0, [India](#) Phone +91 20 6681 8900, info@munters.in, [Indonesia](#) Phone +66 2 642 2670, info@munters.co.th, [Israel](#) Phone +972 3 920 6200, info@munters.co.il, [Italy](#) Phone +39 0183 5211, info@munters.it, [Japan](#) Phone +81 3 5970 0021, mkk@munters.jp, [Korea](#) Phone +82 2 7618 701, munters@munters.co.kr, [Mexico](#) Phone +52 818 2625 400, dhinfo@munters.com, [Singapore](#) Phone +65 7 446 828, info@munters.com.sg, [South Africa and Sub-Sahara Countries](#) Phone +27 11 997 2000, info@munters.co.za, [Spain](#) Phone +39 0183 5211, info@munters.it, [Sweden](#) Phone +46 8 6266 300, info@munters.se, [Thailand](#) Phone +66 2 6422 670, info@munters.co.th, [Turkey](#) Phone +90 262 7513 750, info@muntersform.com, [USA](#) Phone +1 517 676 7070, aghort.info@munters.com, [Export & Other countries](#) Phone +39 0183 5211, info@munters.it

Your closest distributor