

Installation Manual

Trio 20
Swine
Controller



Trio 20 Swine Controller

Ag/MIS/ImGB-2845-10/22 Rev 3.4
P/N: 116874

 Munters

Trio 20 Swine Controller

Installation Manual

Rev 3.4, 05/2025

Software Ver: 8.3.13

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorization of the assembler of the system.

Munters reserves the right to effect modifications to the apparatus in accordance with technical and legal developments.

Index

<i>Chapter</i>		<i>page</i>
1	INTRODUCTION	8
1.1	Disclaimer.....	8
1.2	Introduction	8
1.3	Notes	8
2	PRECAUTIONS	9
2.1	English.....	9
2.1.1	Protection Against Corrosion.....	9
2.1.2	Electrical Guidelines.....	10
2.1.3	Grounding Sensors.....	10
2.1.4	Reducing Interference	10
2.1.5	Filtering	10
2.1.6	Checking the CMOS RTC Batteries Level	11
2.1.6.1	Display Board Battery.....	11
2.1.6.2	Main Board Battery	11
2.1.7	Safety Precautions - Details	12
2.1.8	Grounding the Controller	12
2.1.8.1	Ground Rods	12
2.1.8.2	Ground Wire.....	13
2.1.8.3	Ground Clamps.....	13
2.1.8.4	What Should Be Grounded?	13
2.1.8.5	Lightening Protection.....	13
2.1.8.6	Power Line Protection.....	13
2.2	Française	14
2.2.1	Protection Contre la Corrosion	14
2.2.2	Directives Électriques	14
2.2.3	Raccord à la Terre (Sensores)	15
2.2.4	Réduire les Interférences	15
2.2.5	Filtrage.....	15
2.2.6	Vérification du Niveau des Batteries CMOS RTC	16
2.2.6.1	Batterie du Tableau D'affichage	16
2.2.6.2	Batterie de la Carte Mère	16
2.2.7	Précautions de Sécurité - Détails	17
2.2.8	Mise à la Terre Pour les Contrôleurs.....	17
2.2.8.1	Piquets de Prise de Terre	17

2.2.8.2	Fil de Garde.....	18
2.2.8.3	Colliers de Mise à la Terre	18
2.2.8.4	Quels Elements Doivent etre mis a la Terre?	18
2.2.8.5	Protection Parafoudre	18
2.2.8.6	Protection de Ligne Électrique	19
2.3	Locking the Trio	19
2.4	Product Symbols	19
3	UNIT INSTALLATION.....	20
3.1	What Comes in the Package	20
3.2	Mounting the Unit	20
3.2.1	Knockouts.....	20
3.2.2	Hanging the Unit.....	21
3.3	Board Layout	22
3.4	Wiring Diagrams.....	25
3.4.1	High Voltage Relays.....	25
3.4.2	Alarms and Power	27
3.4.3	Internet Connection	28
3.4.4	Analog Output Devices.....	29
3.4.5	Digital Devices	30
3.4.6	Analog Input Devices.....	31
3.4.6.1	CO2 Sensor Wiring.....	31
3.4.6.2	Temperature Sensor Wiring	33
3.4.6.3	Humidity Sensor Wiring	35
3.4.6.4	Potentiometer Device Wiring	37
3.4.6.5	Ammonia Sensor Wiring.....	38
3.4.7	TRIO RPS	40
3.4.8	Silo Wiring	42
3.4.9	RSU Wiring	44
3.5	Termination.....	45
3.6	Pressure Sensor Hoses	46
3.7	Tech Support/Wi-Fi	47
4	TRIOAIR.....	48
4.1	Access the App	48
4.2	Sign Up.....	48
4.3	Adding a Controller to a Farm During Installation	49
4.4	Offline Registration	51
5	SPECIFICATIONS.....	53
5.1	Trio Specifications	53
5.2	External Devices Specifications	54
6	USING THE TRIO TOUCH SCREEN	56

7	MAPPING AND DEFINING THE INPUT OUTPUT DEVICES.....	58
7.1	Using the Mapping Screen.....	58
7.2	Editing the Relays and Sensors	61
7.3	Mapping Sensors	61
7.3.1	Enabling/Disabling Analog Input Sensors	62
7.3.2	Temperature Sensors.....	63
7.3.2.1	Defining the Temperature Sensors	63
7.3.2.2	Mapping the Temperature Sensors	63
7.3.2.3	Enabling a Weather Station	64
7.3.3	Defining the Ammonia Sensor	65
7.3.4	Defining the CO2 Sensor	65
7.3.5	Defining the Humidity Sensor	66
7.3.6	Defining the Water Meter Sensors.....	66
7.3.7	Defining the Gas Meter Sensors	67
7.3.8	Defining the Feeder Active Sensor	67
7.3.9	Defining the Feeder Line Sensor.....	68
7.4	Mapping Devices	68
7.4.1	Defining the Fans.....	68
7.4.1.1	On-Off Fans.....	69
7.4.1.2	0 – 10 Volt Fans	69
7.4.2	Defining the Stir Fan	70
7.4.2.1	On Off Stir Fan.....	70
7.4.2.2	0 – 10 Volt Stir Fan	70
7.4.3	Defining Heating Devices	71
7.4.3.1	Defining the On/Off Heaters	71
7.4.3.2	Defining the Variable Heaters	71
7.4.3.3	Defining the High Heaters	72
7.4.4	Defining the Cooling Devices	72
7.4.5	Potentiometers, Inlets, Tunnel Doors, Outlets	73
7.4.5.1	Mapping the Potentiometers.....	73
7.4.5.2	Defining the Inlets/Tunnel Doors.....	74
7.4.5.2.1	Potentiometer Calibration.....	74
7.4.5.2.2	Calibrating the Inlets/Tunnel Door	75
7.4.5.3	Defining the Outlet.....	77
7.4.6	Defining the Sprinkler.....	77
7.4.7	Defining the Same As Relays.....	78
7.4.8	Defining the Same As Analog Ports	78
7.4.9	Defining the Timers	79
7.4.10	Defining the Auxiliary Input.....	80
7.4.11	Defining the Measuring Fan.....	80
7.4.12	Defining the Feeder Relay	81

7.4.13	Defining Fail Safe Devices	81
7.5	Mapping the Weighing Devices.....	82
7.5.1	Defining the Silos.....	82
7.5.1.1	Mapping the Silo Scales.....	82
7.5.1.2	Configuring the Silo Scale.....	83
7.5.1.3	Testing the Silo.....	87
7.5.2	Defining the RSU.....	88
7.6	Trio RPS.....	89
7.6.1	Defining the Sensor.....	89
7.6.2	Static Pressure Calibration.....	89
7.7	Testing Devices.....	91
8	APPENDIX A: EXTERNAL DEVICE (PREVIOUS VERSIONS)	93
9	APPENDIX B: SERVICE MANUAL.....	97
9.1	Maintenance	97
9.2	Trouble Shooting.....	98
9.2.1	Internet	98
9.2.2	Electronic Components.....	99
9.3	Spare Parts.....	100
9.3.1	Preliminary Information	100
9.3.2	TRIO 20 Container Spare Parts	101
9.3.3	TRIO 20 Door Cards Spare Parts	103
9.3.4	TRIO 20 Main Container Spare Parts.....	105
9.3.5	Additional Options	106
9.3.6	Cards	107
9.3.6.1	Door Cards.....	107
9.3.6.2	Main Container Cards	110
10	APPENDIX C: TRIO EXPANSION.....	112
10.1	Introduction	112
10.2	Expansion 10	112
10.2.1	Expansion Layout.....	113
10.2.2	TRIO to TRIO 10 Expansion Wiring.....	113
10.2.2.1	Wiring	114
10.2.2.2	Address	115
10.2.2.3	Restart	115
10.2.3	High Voltage Relays.....	116
10.2.4	Power	117
10.3	Expansion 20	117
10.3.1	Expansion Layout.....	118
10.3.2	Expansion Wiring Diagrams.....	118
10.3.2.1	TRIO to TRIO 20 Expansion Wiring	118

10.3.2.2	Wiring	119
10.3.2.3	Address	120
10.3.2.4	Restart	120
10.3.3	High Voltage Relays.....	121
10.3.4	Power	122
10.4	Mapping Devices in Expansion	123
10.5	Expansion Specifications.....	124
10.5.1	Expansion 10 Specifications	124
10.5.2	Expansion 20 Specifications	125
10.5.3	Expansion Specification Details	125
10.6	Expansion Spare Parts	126
10.6.1	Preliminary Information.....	126
10.6.2	Trio Expansion 10 Spare Parts	126
10.6.2.1	Trio Expansion 10 Container Spare Parts.....	127
10.6.2.2	Trio Expansion 10 Main Container Spare Parts	129
10.6.3	Trio Expansion 20 Spare Parts	129
10.6.3.1	Trio Expansion 20 Container Spare Parts.....	130
10.6.3.2	Trio Expansion 20 Main Container Spare Parts.....	132
10.6.4	Additional Options	133
10.6.5	Cards	133
11	APPENDIX D: IT SETUP GUIDE	134
11.1	IT Setup	134
11.2	Subnet Setup	134
11.2.1	Required Equipment	135
11.2.2	Procedure.....	135
11.3	Wi-Fi.....	135
11.4	LAN Cable Information	136
11.4.1	Wire/Optical Ethernet Infrastructure Basics.....	136
11.4.2	Trio Connectivity: 100/1000 GBPS Ethernet Switch	136
11.5	Typical Setups	137
12	WARRANTY	140

1 Introduction

1.1 Disclaimer

Munters reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing a TRIO Swine Controller!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the controller, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters Controllers.

1.3 Notes

Date of release: Jan 2020

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

2 Precautions

CAUTION Protection provided by the equipment can be impaired if the equipment is used in a manner not specified by the manufacturer!

CAUTION There is a risk of explosion if the lithium battery is replaced with an incorrect type. Replace the battery using the same type and manufacturer only.

- English
- Française

2.1 English

- Protection Against Corrosion
- Electrical Guidelines
- Grounding SensorsReducing Interference
- Filtering
- Checking the CMOS RTC Batteries Level
- Safety Precautions - Details
- Grounding the Controller

2.1.1 PROTECTION AGAINST CORROSION

To prevent against corrosion of electrical components:

- Installation location: Install electronic controls in a separate ventilated control room that is protected from extreme temperatures and dirty environments. Place the controls so that the operators can conveniently use the control and read indicators and displays. .
- Keep the Trio closed at all times when a litter or passel is present in the building. In situations where maintenance or repairs are required, close the controller when you finish the work.
- After running the cables through the knockouts, seal the holes with a silicon sealant. If you use silicon sealant with acetic acid cure, keep the controller open and ventilated until cured. Otherwise, the acetic acid will attack metal components, including circuitry.
- When splicing sensors to longer wires, ensure that the splice is waterproof. Use adhesive lined heat shrink (marine grade) to make waterproof connections.
- Use shielded wiring for low level signals. For buried wiring (building to building runs) use high grade jell filled cables that are impervious to moisture.

2.1.2 ELECTRICAL GUIDELINES

- Munters strongly recommends that only panel mount controllers should be installed directly in an electrical closet.
- Placing this unit in proximity (2 meters/6.5 feet or less) to any electrical device that transmits 10 amps or more of current can result in severe signal interference.
- Review the guidelines given in Safety Precautions - Details, page 12 for details. These are vital to ensuring both personal safety and proper controller functioning.

2.1.3 GROUNDING SENSORS

- Every low power device (digital, analog, or communication) must have a shield cable connected to the unit ground strip.

2.1.4 REDUCING INTERFERENCE

- Avoid mixing high voltage wiring with sensor and low voltage wiring.
- Keep the controller as far as possible from heavy contactor boxes and other sources of electrical interference.
- Do not connect communication wire shields, which go from one house to another at both ends. Connect them at one end only. Connection at both ends can cause ground loop currents to flow, which reduce reliability.
- The COM connection for communications is not the shield wire. The COM, RX and TX wires must connect to each other at all controllers.

2.1.5 FILTERING

If this installation includes a power inverter to drive variable speed fans, RLD, RVS-2, or any device that switches high electrical current, install an EMI filter in front of the device. Refer to the inverter documentation.

Any device that transmits high levels of electrical current can cause severe electrical and electromagnetic interference. Therefore, when employing these devices, it is critical that you carefully follow the manufacturer's installation instructions.

In particular verify:

- That the cable shielding between the device and any motor meets industry standards
- Proper grounding of the device's chassis and motor power cable
- Proper grounding of low voltage cable shield wire
- That the controller and device cables are kept in separate conduits or wire bundles




Figure 1: Device Placement

1. Controller
2. High electrical current device
3. Place the controller at least five meters from the device

2.1.6 CHECKING THE CMOS RTC BATTERIES LEVEL

- Display Board Battery
- Main Board Battery

2.1.6.1 Display Board Battery

On the Trio Display Board (refer to Figure X) is a CMOS Battery. This CMOS battery keeps the CPU's real-time clock running when the power is off.

Check the battery once a year. The output must be 2.7 volts (minimum). Authorized personnel only must replace the battery if the output is below the minimum required level or every five years. Use a RENATA-CR2450N battery only.

If the CMOS battery output is below the required minimum, an icon  appears on the touch screen and on the TrioAir app.

CAUTION *If the CMOS battery output is below the required minimum, in the event of a power failure the user will have to reset the time and date when power is reapplied.*

2.1.6.2 Main Board Battery

On the Trio Main Board is a CMOS Battery. This battery is located behind the Scale Card (refer to Figure X). This CMOS battery keeps the board's real-time clock running when the power is off.

Do not test this battery. If the CMOS battery output is below the required minimum, Trio sends an alarm to everyone on the contact list. In this event, an authorized technician must replace the battery with a RENATA-CR2450N battery only.

CAUTION *If the CMOS battery output is below the required minimum, in the event of a power failure the user will have to reset the time and date when power is reapplied.*

Warning: *It is very important to reset the growth date to the required day.*

2.1.7 SAFETY PRECAUTIONS - DETAILS

CAUTION These units must be installed by an authorized electrician. Disconnect the power to avoid electrical shock and damage.

NOTE Installation Category (Over voltage Category) II

- The power supply to the controller should be protected by a 10 amp circuit breaker.
- All electrical connections should comply with National Electrical code (NEC).

2.1.8 GROUNDING THE CONTROLLER

- Ground Rods
- Ground Wire
- Ground Clamps
- What Should Be Grounded?
- Lightening Protection
- Power Line Protection

2.1.8.1 Ground Rods

Ground rods are used to efficiently connect the system to earth where current may be dissipated in the soil.

1. Material: Ground rods should be copper clad or galvanized steel.
2. Diameter: Minimum 5/8", preferably 3/4". Generally the larger the rod diameter, the lower it's resistance to current flow.
3. Length: Minimum 2.5 meters (8 feet), preferably 3-meter (10-foot). A longer ground rod will reach a soil with higher moisture content. Moist soil carries current much better than drier soil.
4. Single grounding: It is important that there is only one grounding location where a rod or series of rods are connected to each other using a ground wire.
5. Independent ground rods will increase the risk of current, from a lightning strike for example, being dissipated through one rod and reentering the system through an adjacent rod.
6. Location: Close to the main circuit breaker panel and in moist soil. For example in an area that is usually wet from a drip or a low spot where water drains. Make sure the area is well protected from damage by lawnmowers, tractors, etc.'
7. Rod installation: Drive the rod into the earth until about 10 cm (4 inches) is left above grade. If it is impossible to drive the rod to the proper depth, it is acceptable to lay the rod horizontally, 80 cm (2.5 feet) below grade.
8. In case the rod is exposed to damage, for example by lawnmowers or tractors it can be installed in a hole, about 20 cm (8 inches) deep so that the rod is about 10 cm under grade and 10 cm above hole level.

NOTE The National Electric Code (NEC) mandates two ground rods unless you can show less than 10 ohms resistance with one rod.

2.1.8.2 Ground Wire

The ground wire is a large copper wire that connects the main circuit breaker panel to the ground rod.

1. Material: Ground rods should be copper clad or galvanized steel.
2. Diameter: Typically, 16 mm (6-gauge) copper wire is sufficient. If the wire run is greater than 20 feet, 20 mm (4-gauge) wire should be used.
3. Length: Minimum 2.5 meters (8 feet), preferably 3-meter (10-foot). A longer ground rod will reach a soil with higher moisture content. Moist soil carries current much better than drier soil.
4. The ground wire should be protected from damage by lawnmowers, tractors, etc. It should be buried at a minimum of 15 cm (6 inches) under grade for protection and enter the house as soon as possible. It is important that the wire not be cut; it should remain continuous.

2.1.8.3 Ground Clamps

Ground wires should not be merely wrapped around a ground rod. Ground clamps are used to attach a ground wire to a ground rod. The most common clamp is known as an acorn clamp. Make sure the ground clamps you select are rated for outdoor use. Do not use pipe clamps rated for inside water lines or hose clamps to attach the ground wire.

2.1.8.4 What Should Be Grounded?

Any equipment that is or could become energized, even accidentally, should be grounded. Current from lightning strikes objects in a random fashion. Accounts of lightning strikes reveal scenarios most of us could not predict.

Electric circuits should be wired with a 3-wire conductor consisting of hot, neutral, and grounding wires. The grounding wire should be attached cleanly and securely to devices or systems to be grounded. The other end of the grounding wire should be attached to the ground bus on the main panel.

2.1.8.5 Lightening Protection

Because of the potential for lightning damage to electronic devices, Munters recommends supplying lightning protection on both the power supply and the communication terminals (if used).

2.1.8.6 Power Line Protection

The RPLP-1 provides lightning protection to the controllers. Refer to the RPLP-1 documentation for detailed wiring instructions. While no lightning protection is perfect, the RPLP-1 significantly enhances the reliability of built-in lightning protection. In addition, Munters recommends using an isolation transformer in front of the RPLP-1 to help block lightning and other transients.

NOTE Common surge protectors provide little additional protection and may trip unnecessarily.

NOTE An isolation transformer preceding the RPLP-1 provides significant additional protection against lightning.

An isolation transformer preceding the RPLP-1 provides significant additional protection against lightning.

2.2 Française

CAUTION *La protection fournie par l'équipement peut être compromise si l'équipement est utilisé d'une façon non spécifiée par le fabricant !*

CAUTION *Il existe un risque d'explosion si la batterie au lithium est remplacée par un type incorrect. Remplacez la batterie uniquement par une batterie du même type et du même fabricant.*

- Protection Contre la Corrosion
- Directives Électriques
- Raccord à la Terre (Sensores)
- Réduire les Interférences
- Filtrage
- Vérification du Niveau des Batteries CMOS RTC
- Précautions de Sécurité - Détails
- Mise à la Terre Pour les Contrôleurs

2.2.1 PROTECTION CONTRE LA CORROSION

Pour éviter la corrosion des composants électriques:

- Installez les commandes électroniques dans une salle de commande ventilée séparée, à l'abri des températures extrêmes et des environnements sales. Placer les commandes de façon à ce que les opérateurs puissent facilement les utiliser et lire les indicateurs et les affichages.
- Gardez le contrôleur fermé à tout moment lorsqu'il y a de la poubelle ou un passage dans le bâtiment. Dans les situations nécessitant une maintenance ou des réparations, fermez le contrôleur lorsque vous avez terminé le travail.
- Après avoir acheminé les câbles à travers les ouvertures, scellez les trous avec un produit d'étanchéité au silicone. Si vous utilisez un mastic de silicone avec durcissement à l'acide acétique, maintenez le contrôleur ouvert et ventilé jusqu'à ce qu'il durcisse. Sinon, l'acide acétique attaquera les composants métalliques, y compris les circuits.
- Lors du raccordement de capteurs à des câbles plus longs, assurez-vous que le raccordement est étanche. Utilisez une gaine thermorétractable adhésive (qualité marine) pour réaliser des connexions étanches.
- Utilisez un câblage blindé pour les signaux de faible niveau. Pour les câbles enterrés (d'un bâtiment à l'autre), utilisez des câbles remplis de gel de haute qualité, imperméables à l'humidité.

2.2.2 DIRECTIVES ÉLECTRIQUES

- Munters recommande vivement que seuls les contrôleurs montés sur panneau soient installés directement dans une armoire électrique.

- Placer cette unité à proximité (2 mètres/6,5 pieds maximum) de tout appareil électrique transmettant 10 ampères ou plus de courant peut entraîner de graves interférences de signal.
- Consulter les consignes données dans Safety Precautions - Details, page XX pour plus de détails. Elles sont essentielles pour garantir à la fois la sécurité personnelle et le bon fonctionnement du contrôleur.

2.2.3 RACCORD À LA TERRE (SENSORES)

- Chaque appareil à faible puissance (numérique, analogique ou de communication) doit être équipé d'un câble blindé raccordé à la barrette de mise à la terre de l'unité.

2.2.4 RÉDUIRE LES INTERFÉRENCES

- Maintenez les câbles basse tension séparés des câbles haute tension. Il doit y avoir au moins un mètre entre le capteur et les câbles électriques.
- Maintenez le contrôleur aussi loin que possible du boîtier lourd de contacteur et des autres sources d'interférences électriques.
- Ne connectez les protections des fils de communication, allant d'une maison à une autre aux deux extrémités. Connectez-les à une seule extrémité uniquement. La connexion aux deux extrémités peut entraîner la circulation de courants dans la boucle de terre, et risquer ainsi de réduire la fiabilité.
- La connexion COM pour les communications n'est pas le fil blindé. Les fils COM, RX et TX doivent être connectés les uns aux autres au niveau de tous les contrôleurs.

2.2.5 FILTRAGE

Si cette installation comprend un onduleur pour entraîner des ventilateurs à vitesse variable, RLD, RVS-2 ou tout autre dispositif qui commute un courant électrique élevé, installez un filtre EMI devant l'appareil. Reportez-vous à la documentation de l'appareil.

- Que le blindage du câble entre l'appareil et tout moteur est conforme aux normes industrielles
- Mise à la terre correcte du châssis de l'appareil et du câble d'alimentation du moteur
- Mise à la terre correcte du fil blindé du câble basse tension
- Que les câbles du contrôleur et de l'appareil sont conservés dans des conduits ou faisceaux de câbles séparés




Illustration 2: Emplacement de l'onduleur

1. Contrôleur
2. Dispositif de courant électrique élevé
3. Placez le contrôleur à au moins cinq mètres de l'appareil

2.2.6 VÉRIFICATION DU NIVEAU DES BATTERIES CMOS RTC

- Batterie du Tableau D'affichage
- Batterie de la Carte Mère

2.2.6.1 Batterie du Tableau D'affichage

Sur le tableau d'affichage Trio (voir Figure X) se trouve une batterie CMOS. Cette batterie CMOS permet à l'horloge à temps réel du CPU de fonctionner lorsque l'alimentation est coupée.

Vérifiez la batterie une fois par an. La sortie doit être de 2,7 volts (minimum). Le personnel autorisé ne doit remplacer la batterie que si la puissance est inférieure au niveau minimum requis ou tous les cinq ans. Utilisez uniquement une batterie RENATA-CR2450N.

Si la puissance de la batterie CMOS est inférieure au minimum requis, une icône  apparaît sur l'écran tactile et sur l'application TrioAir.

CAUTION ATTENTION Si la puissance de la batterie CMOS est inférieure au minimum requis, l'utilisateur devra, en cas de panne de courant, réinitialiser l'heure et la date lorsque l'alimentation sera rétablie.

2.2.6.2 Batterie de la Carte Mère

Une batterie CMOS se trouve sur la carte mère Trio. Cette batterie est située derrière la carte de balance (voir Figure X). Cette batterie CMOS permet à l'horloge à temps réel de la carte mère de fonctionner lorsque l'alimentation est coupée.

Évitez de tester cette batterie. Si la puissance de la batterie CMOS est inférieure au minimum requis, Trio envoie une alarme à tous les contacts de la liste. Dans ce cas, un technicien agréé doit remplacer la batterie par une batterie RENATA-CR2450N uniquement.

CAUTION ATTENTION Si la puissance de la batterie CMOS est inférieure au minimum requis, l'utilisateur devra, en cas de panne de courant, réinitialiser l'heure et la date lorsque l'alimentation sera rétablie.

WARNING! Avertissement : Il est très important de réinitialiser la date au jour requis..

2.2.7 PRÉCAUTIONS DE SÉCURITÉ – DÉTAILS

NOTE Catégorie d'installation (catégorie de surtension) II

- L'alimentation électrique du contrôleur doit être protégée par un disjoncteur de 10 A.
- Tous les raccordements électriques doivent être conformes au National Electrical Code (NEC)

2.2.8 MISE À LA TERRE POUR LES CONTRÔLEURS

- Piquets de Prise de Terre
- Fil de Garde
- Colliers de Mise à la Terre
- Quels Elements Doivent etre mis a la Terre?
- Protection Parafoudre
- Protection de Ligne Électrique

2.2.8.1 Piquets de Prise de Terre

Les piquets de prise de terre sont utilisés pour connecter efficacement le système à la terre, lorsque le courant peut être dissipé dans le sol.

1. Matériel: Les piquets de prise de terre doivent être plaqués cuivre ou en acier galvanisé.
2. Diamètre: Minimum 12,5/20,3 cm, de préférence 7,6/10,16 cm. Généralement, plus le diamètre du piquet est gros, moins sera sa résistance à la circulation du courant.
3. Longueur: Au minimum 2,5 mètres, de préférence 3 mètres. Un piquet de prise de terre plus long atteindra un sol avec une humidité plus élevée. Des sols humides portent beaucoup mieux le courant que des sols plus secs.
4. Mise à la terre unique: Il est essentiel qu'il n'y ait qu'un seul emplacement de mise à la terre auquel un piquet ou une série de piquets sont connectés les uns aux autres à l'aide d'un fil de garde.
5. Des piquets de prise de terre indépendants augmenteraient le risque de courant, provenant par exemple d'un éclair, dissipé par un piquet et réintégrant le système par un piquet adjacent.
6. Emplacement: Près du panneau de panneau du disjoncteur principal et dans un sol humide. Par exemple, dans une zone qui est habituellement humide provenant de précipitation, ou un point bas où l'eau est drainée. Assurez-vous que la zone est bien protégée des dommages pouvant être causés par des tondeuses à gazon, des tracteurs, etc.
7. Installation du piquet: Enfoncez le piquet dans le sol jusqu'à ce qu'il reste 10 cm au dessus du niveau du sol. S'il est impossible d'enfoncer le piquet à une profondeur correcte, vous pouvez poser le piquet horizontalement, 80 cm en dessous du niveau du sol.
8. Dans le cas où le piquet risque d'être endommagé, par exemple, par des tondeuses à gazon ou des tracteurs, il peut être installé dans un trou, à une profondeur d'environ

20 cm pour que le piquet soit environ 10 cm en dessous du niveau du sol et 10 cm au dessus du niveau du trou.

NOTE Le National Electric Code (NEC) a comme impératif l'utilisation de deux piquets de prise de terre, à moins que vous puissiez montrer que la résistance est inférieure à 10 ohms avec un piquet.

2.2.8.2 Fil de Garde

Le fil de garde est un fil cuivré long et épais qui connecte le panneau du disjoncteur principal au piquet de prise de terre.

1. Matériel: Les piquets de prise de terre doivent être plaqués cuivre ou en acier galvanisé.
2. Diamètre: Généralement un fil cuivré de 16 mm (de calibre no. 6) suffit. Si le fil doit parcourir plus de 7m, un fil de 20 mm (de calibre no.4) devrait être utilisé.
3. Longueur: Au minimum 2,5 mètre, de préférence 3 mètres. Un piquet de prise de terre plus long atteindra un sol avec une humidité plus élevée. Des sols humides portent beaucoup mieux le courant que des sols plus secs.
4. Le fil de garde devrait être protégé des dommages pouvant être provoqués par des tondeuses à gazon, des tracteurs, etc. Il devrait être enterré au moins à 15 cm sous le sol pour protection, et être inséré dans la maison aussi vite que possible. Il est important que le fil ne soit pas coupé, il devrait rester entier.

2.2.8.3 Colliers de Mise à la Terre

Des fils de gardes ne devraient pas simplement revêtir un piquet de prise de terre. Des colliers de mise à terre sont utilisés pour attacher un fil de garde au piquet de prise de terre. Le collier le plus ordinaire est un collier ocre. Assurez-vous que les colliers de mise à terre que vous sélectionnez sont adaptés à une utilisation à l'extérieur. N'utilisez pas de collier de serrage adapté pour des conduites d'eau intérieures ou colliers de serrage pour tuyaux flexibles pour rattacher le fil de garde.

2.2.8.4 Quels Elements Doivent etre mis a la Terre?

Tout équipement qui est ou pourrait être sous tension, même accidentellement, devrait être mis à la terre. Les objets qui pourraient être aléatoirement porteurs de la foudre y sont inclus. Des récits de foudre ont montré des cas imprévisibles.

Les circuits électriques devraient être câblés avec un conducteur à 3 fils, constitué d'un fil de garde, d'un fil conducteur neutre et d'un fil chaud. Le fil de garde devrait être rattaché nettement et sûrement aux dispositifs ou aux systèmes à mettre à la terre. L'autre extrémité du fil de garde devrait être rattachée au collecteur de terre sur le panneau principal.

2.2.8.5 Protection Parafoudre

En raison du risque de dommages causés par la foudre sur les appareils électroniques, Munters recommande d'installer une protection contre la foudre sur l'alimentation électrique et les bornes de communication (le cas échéant).

2.2.8.6 Protection de Ligne Électrique

Le RPLP-1 fournit une protection contre la foudre aux contrôleurs. Reportez-vous à la documentation RPLP-1 pour des instructions de câblage détaillées. Bien qu'aucune protection contre la foudre ne soit parfaite, le RPLP-1 améliore considérablement la fiabilité de la protection contre la foudre intégrée. De plus, Munters recommande d'utiliser un transformateur d'isolement devant le RPLP-1 pour aider à bloquer la foudre et d'autres transitoires.

Les parasurtenseurs communs offrent peu de protection supplémentaire et peuvent se déclencher inutilement. Un transformateur d'isolement précédant le RPLP-1 offre une protection supplémentaire importante contre la foudre.

2.3 Locking the Trio

Ensure that the units remains locked to prevent unauthorized access to internal components.




Figure 3: Trio Lock

2.4 Product Symbols


The following labels appear on your controller:



: Caution! Hazardous voltage



: Caution: Refer to the manual



: Main Protective Earthing Terminal

CAUTION IF THE UNIT IS USED IN A MANNER NOT SPECIFIED BY THE MANUFACTURER, THE PROTECTION PROVIDED BY THE EQUIPMENT MAY BE IMPAIRED.

3 Unit Installation

The following sections detail how to mount and wire the TRIO.

NOTE Munters recommends that a trained technician perform the following operations.

- What Comes in the Package
- Mounting the Unit
- Board Layout
- Wiring Diagrams
- Termination
- Pressure Sensor Hoses
- Tech Support/Wi-Fi

3.1 What Comes in the Package

- One TRIO unit
- One hanging bracket
- Four screws
- Two keys

3.2 Mounting the Unit

- Knockouts
- Hanging the Unit

3.2.1 KNOCKOUTS

1. Using the supplied clips and screws, mount the TRIO.
2. On the bottom the TRIO are knockouts used to route the low and high voltage cables.




Figure 4: TRIO Knockouts and PG Size

- Using a screwdriver and a hammer, gently apply pressure to the knockouts.
- Only open the holes that you require.
- Munters recommends removing the knockouts before mounting the unit.
- 16*: Use this knockout for the Ethernet cable.

3. Place the required cables through the cable holders at the bottom of the unit.

CAUTION Run low voltage cables through one knockout and high voltage relay cables through a separate knockout. Do not place them in the same knockout!

3.2.2 HANGING THE UNIT

1. Using the supplied screws, attach the bracket to the wall.




Figure 5: Hang the Bracket

2. Hang the TRIO on the bracket.




Figure 6: Hanging the Unit

3. Close the TRIO enclosure lid carefully and tightly. Use RTV silicon or equivalent sealant to seal the cable holders.

CAUTION Munters strongly recommends that you seal all entry spots with RTV silicon. Failure to do so can lead to damage to the unit.

4. After installation is completed, operate the TRIO for a few hours and re- check for proper operation.

3.3 Board Layout




Figure 7: Main Board layout

1	Analog/digital ports	6	Dipswitches
2	Ground strip	7	Scale Card (option) (CMOS battery is under the card))
3	20 relays	8	Pressure Sensor
4	Alarm relay	9	Power Supply
5	Power ports		




Figure 8: Dipswitches, expanded

- One dipswitch only in each set is raised.
- Only raise a dipswitch if a device is wired to an S port.




Figure 9: Display Board layout, Display Card Version 1.1.0

1	Wireless antenna
2	SD Ports
3	Ethernet Port
4	Heat Sink
5	3V Battery
6	Modem
7	USB Port (used for software upgrades)




Figure 10: Display Board layout, Display Card Version 1.0.4

1	Wireless antenna
2	SIM Port
3	SD Ports
4	Ethernet Port
5	Heat Sink
6	3V Battery
7	Modem

NOTE There is no functional difference between Versions 1.0.4 and 1.1.0. All future versions will support both cards.

3.4 Wiring Diagrams

- High Voltage Relays
- Alarms and Power
- Internet Connection
- Analog Output Devices
- Digital Devices
- Analog Input Devices
- TRIO RPS
- Silo Wiring
- RSU Wiring

NOTE After physically installing and connecting the external input/output devices, perform a Cold Start (System > General Settings > About > Reset Factory Default). Only after the Cold Start do you map the devices.

3.4.1 HIGH VOLTAGE RELAYS




Figure 11: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 12: Relay wiring detailed view




Figure 13: Relay and port numbering

3.4.2 ALARMS AND POWER




Figure 14: Alarm relay and power ports

1	Alarm relay
2	Power ports

- Connect the light or siren device to the alarm relay.

3.4.3 INTERNET CONNECTION




Figure 15: Ethernet port, Display Card Versions 1.0.4 and 1.1.0

CAUTION Connect the internet cable to port 2. Do not connect the cable to port 1.

1	Internal port (do not use this port)
2	Ethernet port
3	RJ-45 cable

3.4.4 ANALOG OUTPUT DEVICES

TRIO supports analog control over a variety of devices.




Figure 16: Analog Output devices (examples)

Connect analog output devices to an AO and a COM port. Ground these devices!




Figure 17: Analog Device Wiring Schematic

CAUTION These devices must be wired to a COM port, not a DCOM port.

3.4.5 DIGITAL DEVICES

Trio supports power meters, gas meters, water meters, auxiliary inputs, and feeder line sensors.




Figure 18: Digital Input devices (examples)




Figure 19: Digital Device Wiring Schematic

- Connect digital devices to a D port and a DCOM port.
- TRIO supports water meters and auxiliary inputs.

CAUTION These devices must be wired to a DCOM port, not a COM port.

3.4.6 ANALOG INPUT DEVICES

- CO2 Sensor Wiring
- Temperature Sensor Wiring
- Humidity Sensor Wiring
- Potentiometer Device Wiring
- Ammonia Sensor Wiring

CAUTION These devices must be wired to a COM port, not a DCOM port.

3.4.6.1 CO2 Sensor Wiring

Refer to the [CO2 Sensor Manual](#) for details on installing this unit.




Figure 20: CO2 Sensor Wiring

Number	Function
1	Red wire: +12V
2	Black wire: -12V (Sig COM)
3	S port
4	COM port
5	Shield wire
Power Supply	
6	Brown wire: phase
7	Blue wire: neutral

CAUTION Connect the shield to the safety ground.




Figure 21: CO₂ Sensor Wiring Schematic

- Connect the CO₂ device to:
 - Controller:
 - S port. In the corresponding dipswitch, raise dipswitch 4 (4-20 mA).
 - COM port
 - Power supply
 - +12V
 - -12V

3.4.6.2 Temperature Sensor Wiring

Refer to the [RTS-2 Manual](#) for details on this sensor.




Figure 22: RTS Wiring

Number	Function
1	COM port (black wire)
2	T port (red wire)




Figure 23: RTS Wiring Schematic

- Connect each RTS sensor to a:
 - T port
 - COM port
 - Grounding strip!
- Notes:
 - Wire all designated T ports before wiring the RTS sensors to the S ports.
 - Connect the black wire to a COM port, not a DCOM port.




Figure 24: RTS S Port Wiring

Number	Function
2	COM port (black wire)
3	S port (red wire)




Figure 25: RTS S Port Wiring Schematic

- Connect each RTS sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 1 (temp)
 - COM port
 - Grounding strip!
- Note:
 - Wire all designated T ports before wiring the RTS sensors to the S ports.
 - Connect the black wire to a COM port, not a DCOM port.

3.4.6.3 Humidity Sensor Wiring

Refer to the [RHS+ SE Manual](#) for further information.




Figure 26: RHS+ Wiring




Figure 27: RHS Pro Wiring

Number	Function
1	COM port (black wire)
2	12V (red wire)
3	S port (white wire)
4	Shield wire




Figure 28: RHS+ Sensor Wiring Schematic

- Connect each RHS+/Pro sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 3 (analog input).
 - COM port.
 - 12VDC port.
 - Grounding strip!

3.4.6.4 Potentiometer Device Wiring




Figure 29: Potentiometer Wiring




Figure 30: Potentiometer Wiring Schematic

- Connect each potentiometer to a:
 - S port. In the corresponding dipswitch, raise dipswitch 2 (potentiometer).
 - COM port.
 - 3.3V port.
 - Grounding strip!

3.4.6.5 Ammonia Sensor Wiring

Refer to the [Ammonia Sensor manual](#) for further information.




Figure 31: Ammonia Sensor Wiring

Number	Function
1	COM port (Green wire)
2	S port (Brown wire)
3	White wire
4	Phase (Brown wire)
5	Neutral (Blue wire)
6	18-30VDC (Red wire)
7	COM (Black wire)
8	20.3 kohm resistor (Note: The resistor comes supplied with the sensor but must be installed on-site.)
9	Quick connector




Figure 32: Ammonia Wiring Schematic

- Connect an ammonia sensor to a:
 - S port. In the corresponding dipswitch, raise dipswitch 3 (analog input).
 - COM port.

3.4.7 TRIO RPS

TRIO RPS serves as a second static pressure sensor for the TRIO Controller. The following section details the installation. Refer to the [RPS Manual](#) for more information. TRIO supports up to two static pressure sensors, one built in and one external. Install the RPS in the second room.




Figure 33: RPS Wiring

Number	Function
1	S port. Raise the corresponding S3 dipswitch.
2	COM port
3	12V
4	Shield wire




Figure 34: RPS Wiring Schematic




Figure 35: RPS Static Pressure Tubes

NOTE After installing the RPS, no Cold Start is required.

3.4.8 SILO WIRING

Wire the Trio to an RJB Junction Box and power supply. For details on how to wire the Junction Box to the load cells, refer to the RJB manual.




Figure 36: Scale Card Wiring to Power Supply and RJB-6

NOTE Connect each RJB-6 white and red wire to matching RSC ports; for example White Ch.1 and Red Ch. 1.

Number	Function
1	Black wire, -5V
2	Green wire, +5V
3	Red, Channel 1 - 6
4	White, Channel 1 - 6
5	COM




Figure 37: RSC Card to Silo Power Supply/RJB-6 Schematic

RJB Wire	RSC Ports
Green	2, 5, 8 (Upper)
Black	2, 5, 8 (Lower)
White	3, 4, 6, 7, 9, 10 (Upper)

Note: Connect each RJB white and red wire to matching ports. For example White Ch.1 and Red Ch.1

3.4.9 RSU WIRING

Refer to the [RSU Manual](#) for further information.




Figure 38: Trio – RSU Wiring

3.5 Termination

Termination, installing or enabling 120-ohm termination resistors at the beginning and end units of a chain, ensures reliable communication in RS-485 infrastructures.

Termination is recommended when the distance between Trio and the final device in the chain is more than 50 meters/165 feet. Trio and Trio Expansion come with a switch to enable termination; an external resistor must be installed on the RSU communication card. Termination may not be required in shorter installations.




Figure 39: Termination Sample Topology




Figure 40: Termination Switch

3.6 Pressure Sensor Hoses





Figure 41: Static Pressure Hoses


3.7 Tech Support/Wi-Fi

To view your unit's network information go to System > General Settings > Network .

You will need this information when speaking with technical support.



- Click Manage.



- Ethernet fields are read-only information.
- Enable Wi-Fi if required.

4 TrioAir

TrioAir is the Munters (desktop and cellphone) app that gives users remote access to their controllers. Trio Controllers are connected directly to the internet via a standard modem. Trio Air is the application used to manage your controllers via the web. In addition to seamless access to your Trio Controllers, Trio Air also offers:

- Remote control and configuration
- Centralized dashboard used to easily compare farms and their controllers.
- Real-time alarms and notifications
- Various levels of access control

There are four basic steps in setting up TrioAir.

- Access the App
- Sign Up
- Creating and Managing a Farm
- Adding Controllers to Farms

The following sections give basic information on signing up for Trio Air and adding controllers to the system. For more information, refer to the [Munters Zendesk](#).

4.1 Access the App

The first step in using TrioAir is to access the application, either on your PC or your cellphone.

- [Desktop App](#)
- [Cellphone App](#)

Users wanting to use TrioAir on their computer, go to <https://www.trioair.net>. Alternatively, you can download the app to your smart phone here:

- [Google Play](#)
- [Apple Store](#)

4.2 Sign Up

In using TrioAir , the first step for any user is to create an account. Once this is done, you can be invited to join farms or create your own farms. The creation process is fairly standard and should be familiar for anyone who has ever created an account for any application.

Note: Munters recommends using Google Chrome.

Sign in to Munters

Email Address
ben.waxman@munters.com

Password
.....

SIGN IN

FORGOT PASSWORD?

Don't have an account? [Sign up now](#)

Scalable Solutions

Munters SaaS scales to your farms exact needs, whether you are a small operation or an industrial complex.

1. Click Sign up now.
2. Enter an email address.
3. Follow the online instructions.
4. Once these steps are completed, an account is created.

Welcome Ben Last.

This is your TrioAir application, use the main explorer menu to navigate through your farms and controllers.

+ CREATE NEW FARM

4.3 Adding a Controller to a Farm During Installation

NOTE The following procedure requires that the Trio be connected to the internet. If the unit is offline, refer to Offline Registration.

The first time that a user power ups a Trio, the following Welcome Screen appears.

Welcome To Trio Controller!



Before using your Trio, please register the controller with TrioAir.

Registration enables access to the following features:



Remote Access

Monitor and control your farm remotely and in real-time.



Manage Data

Access your farm data.



Data Insights

Receive data-driven insights needed to make informed decisions.



Remote Control

TrioAir enables remote control over your controllers in multiple manners.

SKIP FOR NOW

GET STARTED

1. Click Get Started. (If you do not want to register the unit at this time, click Skip For Now). The following screen appears.



TrioAir Registration



P2M58L796

To begin the registration process, follow the instructions below.

Note: You must have a TrioAir account to start this process.


1. On your smartphone or desktop, log into TrioAir.
2. Using a smartphone: -Or- Using a desktop:
Scan the QR code. Go to Farm Settings > Add New Device.
Enter the code manually.
3. Follow the on-line instructions.

2. Follow the instructions on the page. You will need to:

- Select the farm (if there is more than one) to which this Trio is to be added
- Agree to the Terms of Use.


NOTE For more details on the on-line registration process, click [here](#).

NOTE If you do not want to register the unit at this time click **Skip For Now**. The Trio Dashboard shows that the unit is not registered. Click that message to register the Trio.



4.4 Offline Registration

If the Trio unit is off-line, that status appears on the registration screen.



1. Click Offline Registration. The following screen appears.

The screenshot shows a blue-themed registration interface. At the top left is a back arrow icon, and at the top right is a signal strength icon with a red exclamation mark. The title "TrioAir Offline Registration" is centered at the top. Below the title is a QR code. To the right of the QR code, the text "To begin the registration process, follow the instructions below." is displayed, followed by a note: "Note: You must have a TrioAir account to start this process." Three steps are listed: 1. On your smartphone or desktop, log into TrioAir. 2. Using a smartphone: Scan the QR code. -Or- Using a desktop: Go to Farm Settings > Add New Device. Enter the code manually. 3. Follow the on-line instructions. At the bottom left is a "SKIP FOR NOW" button, and at the bottom right is a "CONTINUE" button.

TrioAir Offline Registration

To begin the registration process, follow the instructions below.

Note: You must have a TrioAir account to start this process.

1. On your smartphone or desktop, log into TrioAir.
2. Using a smartphone:
Scan the QR code.
-Or-
Using a desktop:
Go to Farm Settings > Add New Device.
Enter the code manually.
3. Follow the on-line instructions.

SKIP FOR NOW

CONTINUE

2. Click Continue. Follow the online instructions.

NOTE For more details on how to register the Trio while offline, click [here](#).

5 Specifications

- Trio Specifications
- External Devices Specifications

5.1 Trio Specifications

Description	Specification
Input Power Voltage	<ul style="list-style-type: none">• 100 – 240 VAC• 50/60 Hz
Input AC Power	0.35A (at full load)
Relays	1 Amp. Up to 60% of the relays can operate at any given time.
<p><i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i></p>	
Analog Inputs	0 – 3.3 Volts
Analog Output	0 – 10 Volts; maximum load: 20 mA
Digital Inputs	3.3 Volts, 1.5 mA, dry contact
Communication	<ul style="list-style-type: none">• LAN – Standard 10/100 BaseT• Expansion – RS-485: 115 Kbps, 8 bit, even parity <p><i>NOTE Refer to Appendix D: IT Setup Guide, page 134 for more details.</i></p>
Operating and Storage Temperature Range	-10° to +50° C (+14° to +125° F)
Environmental Specifications	<ul style="list-style-type: none">• Altitude: -400 m to 2000 m• Relative Humidity: 20% – 70%• Main supply voltage fluctuation up to 5%• Overvoltage category II• PD: 2
Enclosure	<ul style="list-style-type: none">• Water and dust tight• Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 & F4 on PS card: 3.15A, 250V
Power Cable	<ul style="list-style-type: none">• Copper, 3-wires Phase, Neutral, Ground, 18 AWG minimum• 600 volt insulation

Description	Specification
Certification	   

- **Disconnection device/overcurrent protection:** In the building installation, use a certified 2-pole circuit breaker rated 10A, certified in accordance with the IEC standard 60947-2 (in the US and Canada use a Listed Branch Circuit protective circuit breaker). This step is required to provide overcurrent protection and mains disconnection. The circuit breaker must be easily accessible and marked as the controller disconnect device.
- **Main Supply Voltage:** Permanently connect the controller to the mains in accordance with the relevant national code. Provide fixed wiring inside a flexible conduit. Relays must be suitably protected against overcurrent, using a circuit breaker rated at 10A.
- **Keep the units closed and locked. Only authorized personnel should open and close the units.**

5.2 External Devices Specifications

Table 1: Summary

I/O type	Qty
Analogue Output	8
Analogue Input	6
Digital Input	8
Temperature Sensors	12 maximum (6 dedicated, 6 optional)
Total	34

Table 2: Output Devices

Device type	Maximum Number of Devices	Number of Relay Devices	Number of Analog Devices
Cooling	2	2	N/A
Central Exhaust Cooling	2	2	N/A
Heaters	6	6	6
Inlets	2	2	2
Outlets	1	N/A	1
Tunnel Doors/Curtains	2	2	2
Fans Exhaust/Tunnel	20	20	8
Central Exhaust Fans	20	20	8
Stir Fan	1	1	1
Sprinkler	1	1	N/A

Device type	Maximum Number of Devices	Number of Relay Devices	Number of Analog Devices
Timer	5	5	N/A
Feeder	1	1	N/A
As Relay	20	20	N/A
As Analog Out	8	NA	8
Alarm	1	1	N/A



Table 3: Sensors

Device type	Analog Sensors	Digital Sensors
Temperature Sensors	12	N/A
Humidity Sensors	2	N/A
Outside Humidity Sensor	1	N/A
CO2 Sensor	1	N/A
Ammonia Sensor	1	N/A
Pressure Sensors	2	N/A
Potentiometers	4	N/A
Silos	3	N/A
Power Meters	N/A	2
Water Meters	N/A	4
Gas Meters	N/A	3
Aux. Input	N/A	4
Feed Active Sensor	N/A	1
Feeder Line Sensor	N/A	1
Measuring Fan	N/A	1

Table 4: Other Devices

Device type	Number
RSU-2 Remote Scale Unit	2

6 Using the Trio Touch Screen

	
	Go back to the previous screen
	View the Main menus
	Choose language
	Network settings
	View alarms
	Go back to the main screen
	Settings icon
	Edit parameters
 Settings	Function settings
 Testing	Function test
	Replace the dashboard battery with a RENATA-CR2450N battery.
	Click this icon to delete data stored on that page.

Phone App		
	Click the circle containing the user name to edit personal preferences such as the language, units, name, and more.	
	When the Trio controls two or more rooms or there are two or more houses on a farm, Send to All enables updating certain functions in more than one room or house. Click Send to All and select the required Trios.	

7 Mapping and Defining the Input Output Devices

NOTE Munters recommends that a trained technician perform the following operations.

- Using the Mapping Screen
- Editing the Relays and Sensors
- Mapping Sensors
- Mapping Devices
- Mapping the Weighing Devices
- Trio RPS
- Testing Devices


7.1 Using the Mapping Screen

After wiring devices to the TRIO, each device must be mapped and then defined. Mapping and defining devices enables the system software to control each device's functionality.

CAUTION Mapping **MUST** match the physical wiring! An error message appears if the physical device is not wired to the relay or port as defined on the mapping screen.


To map the devices:

1. Go to System > Device and Sensors.



This screen displays the relays and analog/digital ports. At this point all, icons are undefined.

2. Click .



Devices & Sensors

Devices **Sensors**


- Cooling
- Heater
- Inlet
- Fan
- Stir Fan
- Timer
- Same As Analog
- Same As Relay
- Tunnel Door

Pressure Alarm

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28

- Click **Devices** to map cooling devices, heaters, inlets, fans, stir fans, timers, tunnel doors, outlets, or the alarm relay.
- Click **Sensors** to map auxiliary inputs, sensors (humidity, pressure, temperature, CO₂, ammonia), water meter, and potentiometers.

3. Under Devices or Sensors, click the type of device that you want to map. In the following example, Heater is selected. The screen displays the relays and ports that can be defined as heaters.



Devices & Sensors

Devices **Sensors**

- Cooling
- Heater
- Inlet
- Fan
- Stir Fan
- Timer
- Same As Analog
- Same As Relay
- Tunnel Door


Pressure Alarm

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28

4. Click on the relays and/or ports that you wired to heaters.

- Trio automatically numbers the devices.
- Trio enables selecting up to the maximum number of each device.
- Devices having opening and closing relays require mapping of both relays.


5. Repeat steps 3 and 4 four all the connected devices.



6. After mapping all installed devices, click **SAVE**.

NOTE To un-map a device, click on the required device and hold the icon down.

NOTE If you map a sensor that is not physically connected to the TRIO, an error symbol appears on the designated analog port.



7.2 Editing the Relays and Sensors

1. On the Device and Sensors screen, click a relay or sensor.
2. Click .
3. Edit the parameter(s).
4. Click Save.


7.3 Mapping Sensors

- Enabling/Disabling Analog Input Sensors
- Temperature Sensors
- Defining the Ammonia Sensor
- Defining the CO2 Sensor
- Defining the Humidity Sensor
- Defining the Water Meter Sensors
- Defining the Gas Meter Sensors
- Defining the Feeder Active Sensor
- Defining the Feeder Line Sensor


7.3.1 ENABLING/DISABLING ANALOG INPUT SENSORS

By default, when the user maps an analog input sensor, the sensor is enabled. To disable a sensor:

1. Go to the device and click edit .
2. Move the enable mode icon to off and click Save..



3. On the dashboard, a disabled sensor is marked.




7.3.2 TEMPERATURE SENSORS

- Defining the Temperature Sensors
- Mapping the Temperature Sensors
- Enabling a Weather Station

7.3.2.1 Defining the Temperature Sensors

- ⌚ Define up to 12 analog input ports as temperature sensors (and if required one port as an outside temperature sensor) (refer to Using the Mapping , page 58).



- Define:
 - Offset: This is an optional correction for the temperature sensor. Range: -10° C to +10° C
 - Location: Designate the area in the room where the sensor is located (front/back/center) or designate the sensor as a Piglet Zone sensor.
- The temperature reading shows the measured temperature, including the offset.

7.3.2.2 Mapping the Temperature Sensors

Calculating the temperature data, TRIO takes the following into consideration:

- Tunnel temperature: Select a sensor or a group of sensors to determine the tunnel temperature readings or select if the tunnel run according to the average temperature reading.
- Average temperature: Data from multiple sensors can be averaged. If a sensor fails, the sensor's data is removed from any calculations.
- Device temperature: A sensor (or sensors) can be mapped to a specific device.
- Outside temperature: The temperature sensor defined as an outside temperature is not included in any average calculation.

Map specific temperature sensors to specific devices.

- Go to System > Temperature Definition.

Device	Avg.	Temperature Sensors	Outside
Average		1 3 4	
Cooling 1		3	
Cooling 2		1	
Timer 1			4
Timer 2			✓
Timer 3		1	

- Map the sensors to devices.
 - Define which sensors are used to calculate the average temperature.
 - If an outside temperature sensor is enabled, map timers to it (if required).

NOTE Uninstalling a device in the Relay Layout, Analog Output or TRIAC tables removes the device from this screen.

7.3.2.3 Enabling a Weather Station

To save costs on temperature sensors, one outdoor temperature sensor can provide data to the entire TRIO network.

- In System > Device and Sensors, define one sensor as Outside Temperature.
- Go to System > Control Strategy > Weather Station

	Receive Outside Temp. Broadcast	Disabled

- Enable Receive Outside Temp. Broadcast.

7.3.3 DEFINING THE AMMONIA SENSOR

- ⦿ Define one analog input port as an ammonia sensor (refer to Using the Mapping , page 58).

Ammonia 1	
Offset	0
TEST	

- Define:

- Offset: This is an optional correction for the ammonia sensor. Range: -10 to +10 ppm

7.3.4 DEFINING THE CO2 SENSOR

- ⦿ Define one analog input port as a CO2 port (refer to Using the Mapping , page 58)).

CO2 1	
Offset	0 ppm
TEST	

- Define:

- Offset: This is an optional correction for the CO2 sensor. Range: -500 to +500 ppm

7.3.5 DEFINING THE HUMIDITY SENSOR

- ⦿ Define (refer to Using the Mapping Screen, page 58).
- One or two analog input ports as a humidity sensor
 - One analog input port as an outside humidity sensor

Humidity 2	Outside Humidity 1
Offset 0	Offset 0
TEST	TEST

- Define:
 - Offset: This is an optional correction for the humidity sensor. Range: -10 to +10%


7.3.6 DEFINING THE WATER METER SENSORS

- ⦿ Define up to four digital input ports as a water meter (refer to Using the Mapping , page 58).

Water Meter 1	• Define: <ul style="list-style-type: none">○ Quan/Pulse: Set the water meter's water flow per pulse. Range: 0.0 to 99.9 (unit depends General Settings > User).○ Meter input: Choose drinking water or cooling.
QTY/Pulse 0.3 G Meter Input Drinking Water	
TEST	

7.3.7 DEFINING THE GAS METER SENSORS

- ⦿ Define up to three digital input ports as a gas meter (refer to Using the Mapping , page 58).



- Define:

- Quan/Pulse: Set the gas meter's flow per pulse.
Range: 0.0 to 999 (unit depends on General Settings > User).

7.3.8 DEFINING THE FEEDER ACTIVE SENSOR

- ⦿ Define one digital input port as feeder active (refer to Using the Mapping , page 58).




- Define

- Active State: Select if the relay is normally open or normally close.

7.3.9 DEFINING THE FEEDER LINE SENSOR

- ☛ Define one digital input port as feeder line (refer to Using the Mapping , page 58).



- Define:
 - Active State: Select if the port is normally open or normally closed.
 - Open: The circuit is open when the sensor is activated.
 - Closed: The circuit is closed when the sensor is activated.

7.4 Mapping Devices

- Defining the Fans
- Defining the Stir Fan
- Defining Heating Devices
- Defining the Cooling Devices
- Potentiometers, Inlets, Tunnel Doors, Outlets
- Defining the Sprinkler
- Defining the Same As Relays
- Defining the Same As Analog Ports
- Defining the Timers
- Defining the Auxiliary Input
- Defining the Measuring Fan
- Defining the Feeder Relay
- Defining Fail Safe Devices

7.4.1 DEFINING THE FANS

The following sections detail how to configure fans.

NOTE These settings should be configured by a technician familiar with the fan and inlet/curtain specifications.

Fan air capacity defines how much air is provided when the fans run at full speed. These numbers are used to calculate minimum air requirements.

- ☛ In General Settings > User define the measurement unit.

- Define up to 20 relays or analog output ports as On/Off or 0 – 10 V fans, respectively (refer to Using the Mapping , page 58)).

- On-Off Fans
- 0 – 10 Volt Fans

7.4.1.1 On-Off Fans

Fan 1	
Capacity	0 M3/h
KWh	0
Reverse Relay Output	<input type="checkbox"/>
TEST	

- Define.
 - Capacity: Enter the fan capacity.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.1.2 0 – 10 Volt Fans

Fan 4	
Min. Voltage (V)	0
Max. Voltage (V)	10
Min. Capacity	0 CFM
Max. Capacity	0 CFM
KWh	0
Boost Time (sec.)	5
TEST	

- Define.
 - Minimum/Maximum Voltage: Enter the minimal and maximal voltage used to calibrate the fan speed. For example, if the minimum voltage is set to 2V and the maximum to 8V the controller applies the calculated 0-100% output over a 2V-8V signal.
 - Minimum/Maximum Capacity: Enter the fan's minimum and maximum capacity.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Boost Time: During this amount of time, the controller applied full power to the fan motor (100%).

7.4.2 DEFINING THE STIR FAN

⦿ Define up to two relays as a stir fan (refer to Using the Mapping , page 58)).

- On Off Stir Fan
- 0 – 10 Volt Stir Fan

7.4.2.1 On Off Stir Fan

Stir Fan 1	
KWh	0
Reverse Relay Output	<input type="checkbox"/>
TEST	

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.2.2 0 – 10 Volt Stir Fan

Stir Fan 1	
Min. Voltage (V)	0
Max. Voltage (V)	10
KWh	0
TEST	

- Define:
 - Minimum/Maximum Voltage: Enter the minimal and maximal voltage used to calibrate the fan speed. For example, if the minimum voltage is set to 2V and the maximum to 8V the controller applies the calculated 0-100% output over a 2V-8V signal.
 - KWh: This field displays the amount of kilowatts used. Read-only.

7.4.3 DEFINING HEATING DEVICES

- ⦿ Define up to six relays and/or analogue output ports as heaters in Using the Mapping , page 58.

- On-Off Fans
- 0 – 10 Volt Fans
- Defining the High Heaters

7.4.3.1 Defining the On/Off Heaters

Heater 1	
KWh	0
Operation	Normally Open
Ignition Time (sec.)	0

TEST

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only
 - Reverse Relay Output: Enable this function for Normally Closed Relays.
 - Ignition Time (sec.): Define the delay time between when the heater is turned on and when the gas is ignited.
 - Test checks the relay functionality.

7.4.3.2 Defining the Variable Heaters

Heater 2	
Min. Voltage (V)	0
Max. Voltage (V)	10
KWh	0

TEST

- Define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively. For example, if the minimum voltage is set to 2V and the maximum to 8V the controller applies the calculated 0-100% output over a 2V-8V signal.
 - KWh: This field displays the amount of kilowatts used. Read-only.

7.4.3.3 Defining the High Heaters

High heaters work in conjunction with relay heaters. High heater 1 works with heater 1, high heater 3 works with heater 3, and so on. If there is no corresponding heater to a high heater, the latter does not function. For example, if there are three heaters and four high heaters, high heater 4 does not function.


- ☛ Define up to six relays as high heaters.



- Define:
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.4 DEFINING THE COOLING DEVICES

- ☛ Define up to two relays as cooling devices (refer to Using the Mapping , page 58).



- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Enable this function for Normally Closed Relays.

7.4.5 POTENTIOMETERS, INLETS, TUNNEL DOORS, OUTLETS

- Mapping the Potentiometers
- Defining the Inlets/Tunnel Doors
- Defining the Outlet

7.4.5.1 Mapping the Potentiometers


⌚ Define up to four analogue ports as potentiometers.

As an option, potentiometers enable exact positioning of relay-controlled inlets\tunnel doors when calibrating. If:

- potentiometers are not employed or
- there is a potentiometer failure


opening and closing times are used to calibrate the inlets/tunnel doors.

- Enable/disable the potentiometer.



7.4.5.2 Defining the Inlets/Tunnel Doors

- ⦿ Define up to four relays or analog output ports as inlets or tunnel doors (each device requires two relays or one analogue port) (refer to Using the Mapping , page 58).



- For relay-controllers devices, define:
 - Position: Define how the inlet opening is controlled:
 - By time
 - Potentiometer (relay-controlled inlets or tunnel doors only). Map each inlet/tunnel door to a potentiometer. This option appears only if potentiometers are mapped.
 - Open/Close Time: Measure and enter the amount of time required to fully open or fully close the inlet. These parameters are only enabled when Position/By Time is selected.
 - Open/Close Reverse Relay Output: Enable this function for Normally Closed Relays.
 - Calibrate: Manually calibrate inlets/tunnel doors positioned by a potentiometer. Potentiometer-controlled calibration only.
- For 0 – 10V controlled devices, define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively.
 - Open/Close Time: Measure and enter the amount of time required to fully open or fully close the inlet.

7.4.5.2.1 Potentiometer Calibration

If used, a potentiometer can control the opening and closing with a high degree of precision. When there is no potentiometer, positioning accuracy tends to degrade after the inlets go through several opening and closing cycles.

In order to calibrate the inlets/vents using a potentiometer (refer Potentiometers, Inlets, Tunnel Doors, Outlets, page 73 for details):

:

- Install and map at least one potentiometer.
- Define the position as By Potentiometer.
- Click Calibrate. Calibration must be successful.

In for any reason potentiometer calibration does not function:


- calibration is by time (auto and/or at power up). Time calibration does not fail.
- A potentiometer alarm is generated (if alarms are enabled) . The alarm must be reset to enable potentiometer calibration to function.

7.4.5.2.2 Calibrating the Inlets/Tunnel Door

During installation, the user enables auto-calibration or power up calibration in digital output (relay) inlets. Calibration automatically takes place after the number of inlet movements equals the number of movements required to start calibration or at Trio power up..

Only one inlet or tunnel curtain can be calibrated at a time.

- Relay open occurs when the target position is 100%.
 - Relay close occurs when the target position is 0%.
1. Go to System > Control Strategy > Ventilation .




2. Click .

3. Define:

- Inlets/Tunnel Position: Refer to the User Manual.
- Auto Calibration: If enabled, the inlet or tunnel automatically recalibrates itself.
 - Select 24 hours a day or define a specific time frame.

- Number of Movements: Define the number of steps (number of movements) after which the inlet/tunnel door automatically calibrates.
- Power Up Calibration: Enable this function to have the inlet/tunnel recalibrate itself each time power is applied.



In this situation, click Calibrate to run the Calibration Wizard. If the calibration fails again, check:

- Potentiometer wiring
- Potentiometer
- Inlets' and curtains' opening and closing position. There must be a minimum distance between the two, equivalent to 300 A2D points.

7.4.5.3 Defining the Outlet

⦿ Define one analog output port as an outlet (refer to Using the Mapping , page 58).

Outlet 1	
Min. Voltage (V)	0
Max. Voltage (V)	10
Open Time (sec.)	60
Close Time (sec.)	60

TEST

- Define:
 - Min./Max Voltage: Define the voltage in the analogue output port that corresponds to the 0% and 100% output, respectively. For example, if the minimum voltage is set to 2V and the maximum to 8V the controller applies the calculated 0-100% output over a 2V-8V signal.
 - Open/Close Time: Enter the amount of time required to fully open or fully close the inlet.

7.4.6 DEFINING THE SPRINKLER

⦿ Define one relay as a sprinkler (refer to Using the Mapping , page 58).

Sprinkler 1	
KWh	0
Operation	Normally Open

TEST

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Operation: Define the relay mode.

7.4.7 DEFINING THE SAME AS RELAYS

- ☛ Define up to 20 relays as Same as Relay (refer to Using the Mapping , page 58).

This function enables defining a relay to operate using the parameters defined for another relay. A relay can be tied to any other relay.

Same As Relay –	
Related Channel	0
KWh	0
Operation	Normally Open

TEST

- Define:
 - Related Channel: Define which relay number to follow. Range: 1 – 20
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Operation: Define the relay mode.

7.4.8 DEFINING THE SAME AS ANALOG PORTS

- ☛ Define up to eight relays as Same as Analog Ports (refer to Using the Mapping , page 58).

This function enables defining a relay to operate using the parameters defined for a corresponding analog port. Relays can be mapped to eight specific ports only.

Same As Analog –	
Related Channel	None
KWh	0
Operation	Normally Open


TEST

- Define:
 - Related Channel: Define which port number to follow.
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Operation: Define the relay mode.

Port Number	Related Channel
7	1
8	2
9	3
10	4
21	5
22	6
23	7
24	8

7.4.9 DEFINING THE TIMERS

- ☛ Define up to five relays as timers (refer to Using the Mapping , page 58).



- Define:
 - KWh: This field displays the amount of kilowatts used.
Read-only.
 - Operation: Define the relay mode.

7.4.10 DEFINING THE AUXILIARY INPUT

- ☛ Define up to four digital inputs as auxiliary inputs (refer to Using the Mapping , page 58).

Auxiliary Input 1	
Active State	Open

- Define:
 - Operation: Define the relay mode.

7.4.11 DEFINING THE MEASURING FAN

- ☛ Define one digital input sensor as a measuring fan (refer to Using the Mapping , page 58).

Measuring Fan 1	
Brand	Reventa
Inner	370
Related Fan	None
TEST	

- Define:
 - Brand: Select the fan manufacturer.
 - Inner: Select the fan circumference.
 - Related Fan: If the measuring fan is to be used for compensation, define the fan to be used to provide the extra air. Refer to Ventilation Compensation in the User Manual.

NOTE A relay or port must be defined as a fan for this parameter to be enabled.

7.4.12 DEFINING THE FEEDER RELAY

- ⦿ Define one relay as feeder (refer to Using the Mapping , page 58).

Feeder 1	
KWh	0
Reverse Relay Output	<input type="checkbox"/>
TEST	

- Define:
 - KWh: This field displays the amount of kilowatts used. Read-only.
 - Reverse Relay Output: Select if the relay is normally open or normally close.

7.4.13 DEFINING FAIL SAFE DEVICES

The Failsafe function defines extreme conditions that activate dedicated failsafe relays. These relays activate external devices used to deal with the condition.

- ⦿ Define up to four relays as failsafe relays.

Fail Safe 2	
Reverse Relay Output	<input type="checkbox"/>
TEST	

- Define:
 - Reverse Relay Output: Define the relay mode as Closed.

7.5 Mapping the Weighing Devices

- Defining the Silos
- Defining the RSU

7.5.1 DEFINING THE SILOS


- Mapping the Silo Scales
- Configuring the Silo Scale
- Testing the Silo

7.5.1.1 Mapping the Silo Scales


Trio can support up to three silo scales.

⌚ This function requires a scale card.

1. On the Devices & Sensors > Sensors screen, click Silo. The Scale icon turns brown.




2. Click the Scale icon.
3. Select up to three channels and click Save.




7.5.1.2 Configuring the Silo Scale


The following procedure details how to “zero out” the Trio silo scales. Zeroing out is way to ensure that the unit’s A2D number is accurate (shown in the Silo Icon; 430 in the picture below). To summarize the procedure:

- The user enters the correct amount of feed in the silo while calibrating the silo scale. In the Silo management screen, the user enters “0” (zero). Trio then defines the current A2D signal to be the A2D signal for an empty bin.







1. Define each silo's storage capacity.
2. Click on the silo icon and click Calibrate. The following screen appears:




3. Click Other. The following screen appears:




4. Fill up the silo with a known amount of feed. Munters recommends either a truck filling or a minimum of 500 kilograms.
5. Enter the amount of feed in the silo and press Continue.




The following screen should appear.



6. Go to Batch > Silo Management.




7. Click and change the feed weight to 0.



8. Click Save.

The Trio now displays an accurate A2D number on the silo icon screen.




7.5.1.3 Testing the Silo


1. After calibrating the silo, go to the Silo relay.



2. Click Test.



3. Place a known weight in the silo.




The weight should appear on the screen and the A2D level should rise.

7.5.2 DEFINING THE RSU

The following section details how to define up to two RSU units connected to the Trio (optional). For detailed information on using the RSU, refer to the product manual.

➊ Wire the RSU to the Trio as shown in Figure 38, page 44.

1. Reset the Trio, as shown in General Settings > About.
2. Go to Device & Sensors > Installation > Scale.



3. Click the RSU icon.

4. Click Calibrate.

Follow the instructions given in Configuring the Silo Scale, page 83.

7.6 Trio RPS

- Defining the Sensor
- Static Pressure Calibration

7.6.1 DEFINING THE SENSOR

The following section details how to configure the RPS device.


1. Go to System > Devices & Sensors.

2. Click  . The Devices & Sensors screen appears.

3. Click  .

4. Click Pressure.

5. Define an analog input port as the pressure sensor. In the following screen, ports 5 is defined as the pressure sensor.



6. Go to Climate > Static Pressure and define the parameters.

7.6.2 STATIC PRESSURE CALIBRATION

CAUTION The Static Pressure sensor is factory calibrated. Only calibrate the sensor if you have reason to believe that they are producing inaccurate results.


The Static Pressure should be 0 when there is no ventilation and the house is closed. When the controller A/D counts is 100, this means that there is zero (0) static pressure.

NOTE: Run the controller for a few hours so that the temperature in the box becomes stable and only then calibrate.


CAUTION DO NOT blow the air into the hose to see if the pressure changes! The sensor is sensitive and blowing air can cause irreparable damage.

To calibrate the Static Pressure Sensor:


1. Disconnect the air hoses.
2. Go to *System > Device & Sensors > Pressure*.



3. Click Calibrate.



4. If the A/D count is 100 ± 30 (70 to 130), click Calibrate.
5. If the A/D count is less than 70 or greater than 130:
 - a. Check for blocked air hoses or wind interference.
 - b. Open the Trio. On the Main Board, find the Static Pressure Sensor.



- c. Adjust the zero-pressure reading to approximately 100 by turning the calibration screw.
- d. When the A/D count is within the permitted range, press **Calibrate**.

7.7 Testing Devices

After mapping a device, Trio provides a testing function that enables checking the device's performance.

- Fans: Click Test to test the fan's response. Testing works for fans in Basic, Extra, and Tunnel Mode (Extra/Tunnel Mode: Version 8.3).

Fan 2 Test

⚠ Testing is active.
This relay's control is disabled.

ON
OFF

STOP TESTING

Fan 3 Test

0v

CANCEL
START TESTING


- Relay devices: Click Test > On to ensure that the device turns on.

Cross Auger 1 Testing

ON

STOP TESTING

- Analog output devices: Click Test and move the voltage scale to ensure that the device operates at the proper minimum and maximum voltage levels.



- Analog input devices: Click Test to view the current input results and A2D value. The test function also displays an error message when the input signal is weak or non-existent.

Temperature 6 Testing

A2D	500
Value	22.6°

STOP TESTING

Humidity 2 Testing


! Detected short circuit

68

A2D633

OK

- Acceptable ranges:
 - RTS-2: 200 – 600.
- Digital input devices: Click Test to view the current circuit status (signal close or signal open).



8 Appendix A: External Device (Previous Versions)

Table 5: Output Devices

Device type	Maximum Number of Devices	Number of Relay Devices	Number of Analog Devices
Cooling	2	2	N/A
Central Exhaust Cooling	2	2	N/A
Heaters	6	6	6
Inlets	2	2	2
Outlets	1	N/A	1
Tunnel Doors/Curtains	2	2	2
Fans Exhaust/Tunnel	20	20	8
Central Exhaust Fans	20	20	8
Stir Fan	1	1	1
Sprinkler	1	1	N/A
Timer	5	5	N/A
Auger	2	2	N/A
Feeder	1	1	N/A
Lighting	4	4	N/A
As Relay	30	30	N/A
As Analog Out	8	NA	8
Alarm	1	1	N/A

Table 6: Sensors

Device type	Analog Sensors	Digital Sensors
Temperature Sensors	12	N/A
Humidity Sensors	2	N/A
CO2 Sensors	1	N/A
Ammonia Sensors	1	N/A
Pressure Sensors	2	N/A
Potentiometers	4	N/A
Water Meters	N/A	4

Device type	Analog Sensors	Digital Sensors
Gas Meters	N/A	3
Aux. Input	N/A	4
Feeder Line Sensor	N/A	1
Measuring Fan	N/A	1

Table 7: Trio 20 Swine STD – R4

Devices/Sensors	Output			Measurements	
	Total	Relay	0-10V	Analog	Digital
Cooling	2	2			
Heaters	6	6	6		
Inlets	2	2	2		
Outlets	1	NA	1		
Tunnel Doors/Curtains	2	2	2		
Fans Exhaust/Tunnel	20	20	8		
Stir Fan	1	1	NA		
Sprinkler	1	1			
Timer	5	5			
Feeder	1	1			
As Relay	30	30	NA		
As Analog Output	8	NA	8		
Alarm	1	1			
Temperature Sensors				12	
Humidity Sensors IN				1	
CO2 Sensors				1	
Ammonia Sensors				1	
Pressure Sensors				2	
Potentiometers				4	
Power Meter					2
Gas Meter					2
Water Meters					1
Aux. Input					4
Feeder Line Sensor					1

Table 8: Trio 20 Swine STD - R3

Devices/Sensors	Output			Measurements	
	Total	Relay	0-10V	Analog	Digital
Cooling	2	2			
Heaters	4	4	4		
Inlets	2	2	2		

	Output			Measurements	
Outlets	1	N/A	1		
Tunnel Doors/Curtains	2	2	2		
Fans Exhaust/Tunnel	12	12	8		
Stir Fan	1	1	1		
Sprinkler	1	1			
Timer	5	5			
Feeder	1	1			
As Relay	20	20	N/A		
As Analog Output	8	N/A	8		
Alarm	1	1			
Temperature Sensors				12	
Humidity Sensors IN				1	
CO2 Sensors				1	
Ammonia Sensors				1	
Pressure Sensors				2	
Potentiometers				4	
Power Meter					X
Gas Meter					X
Water Meters					1
Aux. Input					4
Feeder Line Sensor					1

Table 9: Trio 20 Swine STD – R2

	Output			Measurements	
Devices/Sensors	Total	Relay	0-10V	Analog	Digital
Cooling	2	2			
Heaters	4	4	4		
Inlets	2	2	2		
Outlets	1	NA	1		
Tunnel Doors/Curtains	2	2	2		
Fans Exhaust/Tunnel	8	8	8		
Stir Fan	1	1	NA		
Sprinkler	1	1			
Timer	5	5			
Feeder	X	X			
As Relay	20	20	NA		
As Analog Output	8	NA	8		
Alarm	1	1			
Temperature Sensors				12	
Humidity Sensors IN				1	

	Output			Measurements	
CO2 Sensors				1	
Ammonia Sensors				1	
Pressure Sensors				2	
Potentiometers				4	
Power Meter					X
Gas Meter					X
Water Meters					1
Aux. Input					4
Feeder Line Sensor					X


9 Appendix B: Service Manual

- Maintenance
- Trouble Shooting
- Spare Parts


9.1 Maintenance

Perform the following steps to maintain your unit.


- Checking the Battery Level: Check the battery once a year. The output must be 2.7 volts (minimum). Authorized personnel only must replace the battery if the output is below the minimum required level or every five years.
- Visually inspect your unit once a year. Make sure that there are no signs of corrosion or residue on the PCBs. If these issues appear, it means that:
 - the TRIO is installed in an environment with high humidity, ammonia content, or some other destructive agent.
 - There is a lack of (silicon) sealing or that the sealing has degraded.
- Make sure that the silicon seal around the PGs installed in the knockouts is not cracked.
- Check that the gasket is not cracked.



- Check that the gasket around the touch screen is not cracked.



- Look for any signs of burns or browning around the varistors.



- Inspect the shield wiring and main grounding cable; ensure that they are properly connected to the proper ports.

9.2 Trouble Shooting

- Internet
- Electronic Components

9.2.1 INTERNET

The following section describes how to trouble shoot internet problems. If there is no internet connection:

1. Go to System > General Settings > Network Screen. Verify that there is an IP address.
2. Check the cable connections between the switch and the TRIO.
3. Verify that the unit is powered.

NOTE If there is no internet connection, the Main Menu Internet icon is marked.



9.2.2 ELECTRONIC COMPONENTS

Problem: The touch screen doesn't turn on up after applying 115/230VAC.

Solution: Open the TRIO door and:

1. Check main 115/230VAC 3A fuse F2.
 - If required, replace fuse.
2. Check the 12V terminal voltage (COM & 12V).
 - If there is no voltage, there is a problem with the Switched Power Supply. Replace the power supply.
3. Verify that the 5V and 3.3V indicative LEDs of the I/O power board are lit.
4. Verify that the flat cable connecting the I/O board and the display board is in place.
5. Verify that the Green Status LED is flashing.
6. On the TRIO display board, verify that the:
 - RED Status LED is flashing
 - Display's flat cable is firmly hooked up to its connector.

Problem: The screen doesn't reflect changes made in the analog inputs.

Solution:

1. Verify that the position of Dip Switch (S1-S6) corresponds with the relevant analog input.
2. Verify that the analog input terminals' mapping corresponds to the actual wiring.
3. Check that the terminal wire connection of Analog Input of interest coincides with the analog input chosen on the touch screen.

Problem: The screen doesn't reflect the changes in digital inputs.

Solution: Verify that the digital input terminals' mapping corresponds to the actual wiring.

Problem: The Alarm Relay doesn't operate.

Solution: Check fuse F4.

- By default, alarm relay contacts "NO-COM" should be closed.

Problem: The analog output voltage doesn't correspond to the voltage defined on the corresponding analog output terminal.

Solution: Check the load value. The maximum analog output load is 15 mA.

Problem: An analog output terminal has no output voltage.

Solution: Verify that the analog output terminals' mapping corresponds to the actual wiring.

Problem: The display screen appears but does not respond to any touch.

Solution: Check the USB cable between the touch screen card and the TRIO display card.

Problem: There is no 3.3V output for to power the potentiometer(s).

Solution: There is a PPTC fuse F1 on the 3.3V line. Disconnect the potentiometers and using a DVM, check the resistance on the terminal between the 12V output and common ground (COM). The reading should indicate an open circuit.

- If not, the line is damaged.

Problem: The end user doesn't see changes in the data tables.

Solution:

1. Check the Internet cable, going from RJ-45 connector (marked as Ethernet-2). Verify that the connector's LEDs are flashing.
2. Check the Internet cable, going from the power card to the TRIO display's card RJ-45 connector (marked as Ethernet-1). Verify that the connector's LEDs are flashing.


9.3 Spare Parts

- Preliminary Information
- TRIO 20 Container Spare Parts
- TRIO 20 Door Cards Spare Parts
- TRIO 20 Main Container Spare Parts
- Additional Options
- Cards

9.3.1 PRELIMINARY INFORMATION


	TRIO 20
Container	A
Door Cards	B
Main Container Cards	C
Cables and Harnesses	D
MPN	Munters Part Number
DPN	Distributor Part Number

9.3.2 TRIO 20 CONTAINER SPARE PARTS



ID No.	Description	Order Catalog Number
A1.1	TRIO-20 FRONT DOOR TOUCH PLASTIC PART	MPN: 940-99-00005 DPN:
A1.2	TRIO-20 PLASTIC BOX BASE (SP – 207124)	MPN: 940-99-00112 DPN:
A1.3	TRIO HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019 DPN:
A2	TRIO-20 PLASTIC BLUE PANEL (MUNTERS LOGO)	MPN: 940-99-00001 DPN:
A3.1	ONE / ONE PRO - LATCH GENERAL LOCK PLASTIC PART +LOCK FOR LATCH	MPN: 900-99-00217 DPN:
A3.2	GENERAL PLASTIC LATCH	MPN: 900-99-00216 DPN:
A4	TRIO-20 LCD HOLDER V1.0.0 (SP-207125)	MPN: 940-99-00024 DPN:
A5	P4 SCREEN GASKET SILICONE 35 SHORE 75CM(EXTRUSION PROCESS) (SP-204079)	MPN: 940-99-00020 DPN:
A6	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021 DPN:


9.3.3 TRIO 20 DOOR CARDS SPARE PARTS



ID No.	Description	Order Catalog Number	
B1	TRIO-20 LCD KIT (DISPLAY + LVDS CARD), [+ USB CABLE *]	MPN: 940-99-00002 DPN:	OR
B2.1	TRIO 20 -PIG- DISPLAY CARD AND SOM VARISCITE CARD WITH HEATSINK AND FAN	MPN: 940-99-00041 DPN:	
B2.2	TRIO 20 -PIG-CN- DISPLAY CARD AND SOM VARISCITE CARD WITH HEATSINK AND FAN	MPN: 940-99-00043 DPN:	CHINA ONLY
B2a	TRIO 20 DISPLAY CARD (TRIO-DISPLAY)	MPN: 940-99-00004 DPN:	
B2a.a	BAT COIN 3V FOR SOCKET(SP-450009)	MPN: 999-99-00386 DPN:	
B2b.1	TRIO 20 -PIG- SOM VARISCITE CARD WITH HEATSINK AND FAN	MPN: 940-99-00040 DPN:	OR
B2b.2	TRIO 20 -PIG-CN- SOM VARISCITE CARD WITH HEATSINK AND FAN	MPN: 940-99-00042 DPN:	
B2b.a	TRIO 20 HEATSINK AND FAN FOR SOM CARD	MPN: 940-99-00026 DPN:	
B2b.b	FAN FOR TRIO SOM (SP-204152)	MPN: 940-99-00025 DPN:	
B2b.c	TRIO 20 ANTENNA WIFI MOLEX 15cm CABLE U.FL/I-PEX MHF 2.4GHz 2.8dBi 50ohm (SP-491009)	MPN: 940-99-00035 DPN:	

ID No.	Description	Order Catalog Number
D1	VIDEO FLAT CABLE 0.02" (0.50 mm) Type 1,152.4 mm	MPN: 940-99-00012 DPN:
D2	USB CABLE FOR Vitek DISPLAY (SP-140672)	MPN: 940-99-00027 DPN:
D3	NETWORK CABLE RJ45 (8 WIRES, 0.5 METERS)	MPN: 940-99-00011 DPN:
D4	FLAT FF14P 25CM F"D>_V1.0.0 (SP-141161)	MPN: 999-99-00457 DPN:

9.3.4 TRIO 20 MAIN CONTAINER SPARE PARTS



ID No.	Description	Order CatalogNumber
C1	TRIO-20 MAIN CARD (TRIO-20 MAIN)	MPN: 940-99-00003 DPN:
C1.1	SWPS LPV-60-12 Mean Well 100-240V 12V 60W (SP-370193)	MPN: 900-99-00264 DPN:
C1.a	BAT COIN 3V FOR SOCKET(SP-450009)	MPN: 999-99-00386 DPN:
C2	TRIO-20 POU SETRA PRESSURE CARD	MPN: 901-99-00013 DPN:


9.3.5 ADDITIONAL OPTIONS



ID No.	Description	Order CatalogNumber
ADO 1	TEMPERATURE SENSOR BLACK-RTS-2-POU	MPN: 918-01-00001 DPN:
ADO 2	HUMIDITY SENSOR-RHS-POU-ROT-SE-10PL	MPN: 917-02-00003 DPN:
ADO 3	STATIC PRESSURE SET - AC3G/SE/PL/TRIO - PIG	MPN: 901-99-00028 DPN:
ADO 3.a	TUBES AND FILTERS FOR RPS (NO RPS CARD)	MPN: 999-99-00503 DPN:
ADO 4	STATIC PRESSURE (EXTERNAL) SENSOR-RPS-PIG-MUR	MPN: 920-03-10001 DPN:
ADO 5	CO2-PIG-EN-MUR	MPN: 919-01-10005 DPN:
ADO 6	AMMONIA-POU-MUN	MPN: 929-01-00002 DPN:




9.3.6 CARDS

- Door Cards
- Main Container Cards


9.3.6.1 Door Cards

Card	Description	Munters Ordering Number
	250061: LCD TFT 10.1' VT101C-KC17-B07A Vitek Or AM- 102460002TMQW- TA0H AmpireOr TWS2101RBT20C APEX	940-99-00002
	140672: USB CABLE FOR Vitek\Ampire DISPLAY	940-99-00027
	TRIO 20 -PIG- DISPLAY CARD AND SOM VARISCITE CARD WITH HEATSINK AND FAN	940-99-00041

Card	Description	Munters Ordering Number
	TRIO 20 -PIG-CN-DISPLAY CARD AND SOM VARISCITE CARD WITH HEATSINK AND FAN <u>NOTE: CHINA ONLY</u>	940-99-00043
	R-TRIO-DISPLAY: TRIO 20 DISPLAY CARD (TRIO-DISPLAY)	940-99-00004
	TRIO 20 -PIG- SOM VARISCITE CARD WITH HEATSINK AND FAN	940-99-00040

Card	Description	Munters Ordering Number
	TRIO 20 -PIG-CN-SOM VARISCITE CARD WITH HEATSINK AND FAN <u>NOTE: CHINA ONLY</u>	940-99-00042
	TRIO 20 HEATSINK AND FAN FOR SOM CARD	940-99-00026
	204152: FAN FOR SOM CARD HEATSINK	940-99-00025
	491009: ANTENNA WI-FI MOLEX 1461530150 15cm CABLE, U.FL/I-PEX MHF	940-99-00035

9.3.6.2 Main Container Cards

Card	Description	Munters Ordering Number
	R-TRIO-20-MAIN: MUNTERS ROTEM MIDDLE RANGE 2CPU	940-99-00003
	370193: SWPS LPV-60-12 Mean Well 100-240V 12V 60W	900-99-00264
	STATIC PERSSURE SET-AC3G/SE/PL/TRIO-PIG	901-99-00028

Card	Description	Munters Ordering Number
	TUBES AND FILTERS FOR RPS (NO RPS CARD)	999-99-00503

10 Appendix C: TRIO Expansion

- Introduction
- Expansion 10
- Expansion 20
- Mapping Devices in Expansion
- Expansion Specifications
- Expansion Spare Parts

10.1 Introduction

- Observe all the safety rules given in Precautions, page 9.
- Install the unit according to the instructions given in Unit Installation, page 20.

10.2 Expansion 10

- Expansion Layout
- TRIO to TRIO 10 Expansion Wiring
- High Voltage Relays
- Power

10.2.1 EXPANSION LAYOUT




Figure 42: Board layout

1	10 relays
2	RS-485 ports
3	Power ports
4	Ground strip
5	Address dipswitch (refer to Address, page 120)

10.2.2 TRIO TO TRIO 10 EXPANSION WIRING

Connecting the Trio to its Expansion Unit consists of three steps:

- Wiring
- Address
- Restart

10.2.2.1 Wiring




Figure 43: Wiring diagram

- The cable between the controller and the expansion unit should be a 4 wire twisted shielded cable (22 or 24 AWG).
- 1 – red wire
- 2 – black wire

10.2.2.2 Address

The Trio can support one expansion unit. Verify that both dipswitches in the Modbus Address are set to ON.




Figure 44: Expansion Address

10.2.2.3 Restart

After connecting the units and verifying the Modbus address, reset the factory settings.

1. Go to System > General Settings >
2. Click
3. Follow the on-line instructions. You have the option of backing up the settings.
Refer to the User Manual for more information.

10.2.3 HIGH VOLTAGE RELAYS




Figure 45: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 46: Relay and port numbering

10.2.4 POWER




Figure 47: Power ports

10.3 Expansion 20

- Expansion Layout
- Expansion Wiring Diagrams
- High Voltage Relays
- Power

10.3.1 EXPANSION LAYOUT




Figure 48: Board layout

1	20 relays
2	RS-485 ports
3	Power ports
4	Ground strip
5	Address dipswitch (refer to Address, page 120)

10.3.2 EXPANSION WIRING DIAGRAMS

- TRIO to TRIO 20 Expansion Wiring
- High Voltage Relays
- Alarms and Power

10.3.2.1 TRIO to TRIO 20 Expansion Wiring

Connecting the Trio to its Expansion Unit consists of three steps:

- Wiring
- Address
- Restart

10.3.2.2 Wiring




Figure 49: Wiring diagram

- The cable between the controller and the expansion unit should be a 4 wire twisted shielded cable (22 or 24 AWG).
- 1 – red wire
- 2 – black wire

10.3.2.3 Address

The Trio can support one expansion unit. Verify that both dipswitches in the Modbus Address are set to ON.




Figure 50: Expansion Address

10.3.2.4 Restart

After connecting the units and verifying the Modbus address, reset the factory settings.

1. Go to System > General Settings >
2. Click
3. Follow the on-line instructions. You have the option of backing up the settings.
Refer to the User Manual for more information.

10.3.3 HIGH VOLTAGE RELAYS




Figure 51: High voltage devices (examples)

1	Example of devices
---	--------------------

NOTE The relays control motors and heating devices via contactors, not directly.




Figure 52: Relay and port numbering

10.3.4 POWER




Figure 53: Power ports

10.4 Mapping Devices in Expansion

☛ Install and wire the Expansion unit to the TRIO and to the external devices before beginning.

☛ After wiring the Expansion unit to TRIO, go to System > General Settings > Info 

Reset Factory Settings 

and click . Follow the online instructions.


TRIO will not recognize the Expansion until this step is performed.

After wiring devices to the TRIO Expansion Unit, each device must be mapped and then defined. Mapping and defining devices enables the system software to control each device's functionality.


CAUTION *Mapping MUST match the physical wiring! An error message appears if the physical device is not wired to the relay or port as defined on the mapping screen..*

To map the devices:

1. Go to System > Device and Sensors.



2. Click Expansion.



3. Map the devices as detailed in the TRIO manual. Refer to Using the Mapping , page 58 for more information.

10.5 Expansion Specifications

- Expansion 10 Specifications
- Expansion 20 Specifications
- Expansion Specification Details

10.5.1 EXPANSION 10 SPECIFICATIONS

Parameter	Specifications
Input Power Voltage	115/230 VAC, 50/60 Hz
Input AC Power	0.2A
Maximum number of relays operating simultaneously	10
<i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i>	
Communication	RS-485: 115 Kbps, 8 bit, even parity
Operating Temperature Range	-10° to +50° C (+14° to +125° F)
Storage Temperature Range	-20° to +80° C (-4° to +176° F)
Environmental Specifications	<ul style="list-style-type: none">• Altitude: -400 m to 2000 m• Relative Humidity: 20% – 90%• Main supply voltage fluctuation up to +10 – 20%• Overvoltage category II
Enclosure	<ul style="list-style-type: none">• Water and dust tight• Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 on PS card: 3.15A, 250V
Certification	   

10.5.2 EXPANSION 20 SPECIFICATIONS

Parameter	Specifications
Input Power Voltage	115/230 VAC, 50/60 Hz
Input AC Power	500 mA
Maximum number of relays operating simultaneously	15
<i>Note: Running relays at the above current levels provides between 50,000 – 100,000 switching operations.</i>	
Communication	RS-485: 115 Kbps, 8 bit, even parity
Operating Temperature Range	-10° to +50° C (+14° to +125° F)
Storage Temperature Range	-20° to +80° C (-4° to +176° F)
Environmental Specifications	<ul style="list-style-type: none"> • Altitude: -400 m to 2000 m • Relative Humidity: 20% - 90% • Main supply voltage fluctuation up to +10 - 20% • Overvoltage category II • PD: 2
Enclosure	<ul style="list-style-type: none"> • IP: 52 • Indoor use only
Dimensions (H/W/D)	403 x 324 x 141 mm/16 x 13 x 5.6 inches
Fuses	Fuse F2 on PS card: 3.15A, 250V
Certification	   

10.5.3 EXPANSION SPECIFICATION DETAILS

- **Disconnection device/overcurrent protection:** In the building installation, use a certified 2-pole circuit breaker rated 10A, certified in accordance with the IEC standard 60947-2 (in the US and Canada use a Listed Branch Circuit protective circuit breaker). This step is required to provide overcurrent protection and mains disconnection. The circuit breaker must be easily accessible and marked as the controller disconnect device.
- **Main Supply Voltage:** Permanently connect the controller to the mains in accordance with the relevant national code. Provide fixed wiring inside a flexible conduit. Relays must be suitably protected against overcurrent, using a circuit breaker rated at 10A.
- **Keep the units closed and locked.** Only authorized personnel should open and close the units.

10.6 Expansion Spare Parts

- Preliminary Information
- Trio Expansion 10 Spare Parts
- Trio Expansion 20 Spare Parts
- Additional OptionsCards


10.6.1 PRELIMINARY INFORMATION

	TRIO EXP 10	TRIO EXP 20
Container	A	C
Main Container Cards	B	D
Cables and Harnesses	N/A	E
MPN	Munters Part Number	
DPN	Distributor Part Number	

10.6.2 TRIO EXPANSION 10 SPARE PARTS


- Trio Expansion 10 Container Spare Parts
- Trio Expansion 10 Main Container Spare Parts

10.6.2.1 Trio Expansion 10 Container Spare Parts



ID No.	Description	Order Catalog Number	Note
A1.1	TRIO FRONT DOOR EXP PLASTIC PART V1.0.0 (SP: 207129)	MPN: 940-99-00028 DPN:	
A1.2	TRIO-20 PLASTIC BOX BASE (SP: 207124)	MPN: 940-99-00112 DPN:	
A1.3	TRIO HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019 DPN:	OR
A2.1	TRIO-20 PANEL PLASTIC PART BLUE LOGO MUNTERS + PART BLUE	MPN: 940-99-00001 DPN:	
A2.2	TRIO PANEL PLASTIC PART RED RAL 3020 NO LOGO (SP-207138)	MPN: 940-99-00045 DPN:	
A3.1	GENERAL PLASTIC LATCH	MPN: 900-99-00216 DPN:	
A3.2	ONE/ONE PRO LATCH GENERAL LOCK PLASTIC PART + LOCK FOR LATCH	MPN: 900-99-00217 DPN:	
A4	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021 DPN:	

10.6.2.2 Trio Expansion 10 Main Container Spare Parts




ID No.	Description	Order Catalog Number
B1	TRIO-EXP 10 CARD (SP: R-TRIO-EXP10)	MPN: 940-99-00029
		DPN:
B1.1	SWPS APV-16-12 Mean Well 115V/230V 12V 16W (SP: 370153)	MPN: 999-99-00338
		DPN:

10.6.3 TRIO EXPANSION 20 SPARE PARTS


- Trio Expansion 20 Container Spare Parts
- Trio Expansion 20 Main Container Spare Parts

10.6.3.1 Trio Expansion 20 Container Spare Parts



ID No.	Description	Order Catalog Number	Note
C1.1	TRIO FRONT DOOR EXP PLASTIC PART V1.0.0 (SP: 207129)	MPN: 940-99-00028 DPN:	
C1.2	TRIO-20 PLASTIC BOX BASE (SP: 207124)	MPN: 940-99-00112 DPN:	
C1.3	TRIO HINGE PLASTIC PIN V1.0.0 (SP-207128)	MPN: 940-99-00019 DPN:	OR
C2.1	TRIO-20 PANEL PLASTIC PART BLUE LOGO MUNTERS + PART BLUE	MPN: 940-99-00001 DPN:	
C2.2	TRIO PANEL PLASTIC PART RED RAL 3020 NO LOGO (SP-207138)	MPN: 940-99-00045 DPN:	
C3.1	GENERAL PLASTIC LATCH	MPN: 900-99-00216 DPN:	
C3.2	ONE/ONE PRO LATCH GENERAL LOCK PLASTIC PART + LOCK FOR LATCH	MPN: 900-99-00217 DPN:	
C4	MID-RANGE MAIN GASKET V1.0.0 (SP-207122)	MPN: 940-99-00021 DPN:	

10.6.3.2 Trio Expansion 20 Main Container Spare Parts



ID No.	Description	Order Catalog Number
D1	TRIO-EXP 10 CARD (SP: R-TRIO-EXP10)	MPN: 940-99-00029
		DPN:
D1.1	SWPS APV-16-12 Mean Well 115V/230V 12V 16W (SP: 370153)	MPN: 999-99-00338
		DPN:
D2	TRIO EXP 10 RELAY ADDIT CARD (TRIO-EXP-10R)	MPN: 940-99-00159
		DPN:

ID No.	Description	Order Catalog Number
E1	FLAT FF14P 34cm (TRIO EXP)<F"D_F"D> (SP-141201)	MPN: 940-99-00168
		DPN:

10.6.4 ADDITIONAL OPTIONS

ID No.	Description	Order Catalog Number
ADO 1	Trio Expansion: 10 Relays To 20 Relays Upgrade Kit	MPN: 940-99-00169 DPN:

10.6.5 CARDS

Card	Description	Munters Ordering Number
A photograph of a green printed circuit board (PCB) labeled "R-TRIO-EXP10: TRIO EXP 10 CARD". The board features a central integrated circuit (IC), several surface-mount components, and a large component labeled "APV16-12". It has multiple terminal blocks for connecting external relays and power sources. A small blue label on the right side reads "TRI GND TRIP".	R-TRIO-EXP10: TRIO EXP 10 CARD	940-99-00029
A photograph of a white rectangular power supply unit labeled "APV-16-12". The label includes technical specifications: INPUT: 100-240V~, 5.5A MAX; OUTPUT: 12VDC 1.33A; IP42 LPS; CE; RoHS. It has two black wires attached to the back.	370153: SWPS APV-16-12 Mean Well 115V/230V 12V 16W	999-99-00338
A photograph of a green PCB labeled "R-TRIO-EXP-10R: CARD EXP RLY ADDIT 10 TRIO". The board is populated with numerous surface-mount components, including several relays arranged in a grid. A small "Munters" logo is visible at the bottom right of the board.	R-TRIO-EXP- 10R: CARD EXP RLY ADDIT 10 TRIO	940-99-00159

11 Appendix D: IT Setup Guide

The following information is intended for the IT specialist/ISP personnel setting up the internet network between the Communicator 2.0 and Trio Controllers.

- IT Setup
- Subnet Setup
- Wi-Fi
- LAN Cable Information
- Typical Setups

11.1 IT Setup

- Communicator 2.0 and Trio controllers must be on same subnet LAN.

WARNING! *In order to ensure continual communication, the Communicator 2.0 and Trio LAN must be an independent dedicated subnet.*

- Employ a standard home router, using the default settings, and all devices on the same router.
- On the local network, Communicator 2.0 and Trio must have same the subnet mask (subnet mask must be **255.255.255.0**).
- Three first sections of the Communicator 2.0 and Trio IP address must have the same numbers (for example **192.168.1.x**).
- Network must be IPv4.

NOTE Munters recommends have a dedicated subnet for the Communicator 2.0/Trio network.

- The local network can employ a firewall on condition that the following ports are open:

<ul style="list-style-type: none">• Zero-configuration networking (zeroconf)• MQTT• 15672• 4200• UDP port 1900• 5355	<ul style="list-style-type: none">• RabbitMQ• AMQPT• 1883• UDP port 5353• TCP port 3689• 1883 MQTT
---	---
- Communicator 2.0 has a built-in firewall; all outgoing ports are closed. Incoming ports 8- and 443 are open.

11.2 Subnet Setup

To create a subnet within an industrial network that uses its own DHCP server with the range **192.168.1.1 - 192.168.1.255** or **192.168.2.1 - 192.168.2.255**, you need networking equipment capable of isolating and managing traffic.

- Required Equipment
- Procedure

CAUTION Only Communicator 2.0 for Trio and Trio Controllers can be part of this subnet.

11.2.1 REQUIRED EQUIPMENT

- Router or Layer 3 Switch:
 - Capable of creating and managing subnets
 - Allows routing between subnets if required
 - Example: Cisco ISR, Ubiquiti EdgeRouter, or MikroTik
- Managed Switch (Optional):
 - If you need to segment traffic further with VLANs
 - Example: Cisco Catalyst, TP-Link JetStream, or similar
- DHCP Server or Router with DHCP Capabilities:
 - Configure a separate DHCP scope for the new subnet
 - Many modern routers support multiple DHCP scopes
- Firewall (Optional, for added security):
 - To enforce rules between the industrial network and the new subnet

11.2.2 PROCEDURE

1. Define the Subnet:

- Choose a new IP range (e.g., 192.168.2.0/24)

2. Set Up the Router:

Configure a new interface or sub-interface for the new subnet

Assign an IP address (e.g., 192.168.2.1) to this interface

3. Configure DHCP for the New Subnet:

On the router or a dedicated DHCP server, set a DHCP scope (e.g., 192.168.2.2 - 192.168.2.254)

4. Isolate Traffic:

Ensure the industrial network (192.168.1.0/24) and the new subnet (e.g., 192.168.2.0/24) are isolated

Use VLANs or routing rules to control traffic flow

5. Connect Devices:

Connect devices in the new subnet to the appropriate port on the router/switch

11.3 Wi-Fi

Munters strongly recommends against using Wi-Fi as the internet network. Anyone wanting to use a Wi-Fi network should consult with his IT specialist.

11.4 LAN Cable Information

- Wire/Optical Ethernet Infrastructure Basics
- Trio Connectivity: 100/1000 GBPS Ethernet Switch

11.4.1 WIRE/OPTICAL ETHERNET INFRASTRUCTURE BASICS

- Wire Ethernet 1100/1000 BaseT Copper
 - Media – CAT5E or CAT6 Cable with maximum segment length of 100 meters
- Optical Ethernet 1000Base-X Optical
 - 1000Base-SX Media: Short Haul multi-mode optic fiber (MMF) with maximum segment length of 220 meters (62.5/125µm type) or 550 meters (50/125µm type)
 - 1000Base-LX Media: Long Haul single-mode optic fiber (SMF) with maximum segment length of 10000 meters
- Connectivity
 - Connectivity is Point-to-Point using 100/1000 Switches
 - Low latency network. If the DHCP takes too long (over 3 minutes) to assign IP addresses to controls, it may cause lost communication alarms when controls reset.
- Equipment
 - Wire Switch serves for Ethernet switching over wire connectivity
 - Could be with preinstalled specific Optic Transceiver (short or long haul)
 - Could be with the SFP port, serving for pluggable SFP Optic Transceiver
 - SFP Transceiver pluggable device serving to transmit data over optic fiber
 - 1000Base-SX SFP serves for multi-mode optic fiber (MMF) of 62.5/125µm type or 50/125µm type
 - 1000Base-LX SFP serves for single-mode optic fiber (SMF)
 - Media Converters serve for converting from optics to wire and vice versa. This is used for segments over 100 meters / 330 feet.

11.4.2 TRIO CONNECTIVITY: 100/1000 GBPS ETHERNET SWITCH

- The switch is wired to the router and modem to access the Internet.
- Switches can be wired to each other by Ethernet cables, each one splitting off to other devices.
- Gigabit switches support 100 and 1,000 Mbps.

11.5 Typical Setups




Figure 54: Typical Poultry Installation 1




Figure 55: Typical Poultry Installation 2




Figure 56: Typical Swine Installation

12 Warranty

Warranty and technical assistance

Munters products are designed and built to provide reliable and satisfactory performance but cannot be guaranteed free of faults; although they are reliable products they can develop unforeseen defects and the user must take this into account and arrange adequate emergency or alarm systems if failure to operate could cause damage to the articles for which the Munters plant was required: if this is not done, the user is fully responsible for the damage which they could suffer.

Munters extends this limited warranty to the first purchaser and guarantees its products to be free from defects originating in manufacture or materials for one year from the date of delivery, provided that suitable transport, storage, installation and maintenance terms are complied with. The warranty does not apply if the products have been repaired without express authorisation from Munters, or repaired in such a way that, in Munters' judgement, their performance and reliability have been impaired, or incorrectly installed, or subjected to improper use. The user accepts total responsibility for incorrect use of the products.

The warranty on products from outside suppliers fitted to TRIO, (for example antennas, power supplies, cables, etc.) is limited to the conditions stated by the supplier: all claims must be made in writing within eight days of the discovery of the defect and within 12 months of the delivery of the defective product. Munters has thirty days from the date of receipt in which to take action, and has the right to examine the product at the customer's premises or at its own plant (carriage cost to be borne by the customer).

Munters at its sole discretion has the option of replacing or repairing, free of charge, products which it considers defective, and will arrange for their despatch back to the customer carriage paid. In the case of faulty parts of small commercial value which are widely available (such as bolts, etc.) for urgent despatch, where the cost of carriage would exceed the value of the parts, Munters may authorise the customer exclusively to purchase the replacement parts locally; Munters will reimburse the value of the product at its cost price.

Munters will not be liable for costs incurred in demounting the defective part, or the time required to travel to site and the associated travel costs. No agent, employee or dealer is authorised to give any further guarantees or to accept any other liability on Munters' behalf in connection with other Munters products, except in writing with the signature of one of the Company's Managers.

WARNING: In the interests of improving the quality of its products and services, Munters reserves the right at any time and without prior notice to alter the specifications in this manual.

The liability of the manufacturer Munters ceases in the event of:

- dismantling the safety devices;

- use of unauthorised materials;
- inadequate maintenance;
- use of non-original spare parts and accessories.

Barring specific contractual terms, the following are directly at the user's expense:

- preparing installation sites;
- providing an electricity supply (including the protective equipotential bonding (PE) conductor, in accordance with CEI EN 60204-1, paragraph 8.2), for correctly connecting the equipment to the mains electricity supply;
- providing ancillary services appropriate to the requirements of the plant based on the information supplied with regard to installation;
- tools and consumables required for fitting and installation;
- lubricants necessary for commissioning and maintenance.

It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer.

Dismantling and assembly must be performed by qualified technicians and according to the manufacturer's instructions.

The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Requests for technical assistance and spare parts can be made directly to the nearest [Munters office.](#)

