



**NOTES:**

- A. ATTACH 2 ANGLE BRACKETS TOGETHER WITH 1 BOLT AND NUT AS SHOWN.
- B. ATTACH (3) ANGLE BRACKET GROUPS TO T-BARS THROUGH PRE-DRILLED HOLES AS SHOWN PER 12' SECTION. SET T-BAR SUPPORT ON TOP OF BOTTOM COOLING PAD.
- C. ATTACH THE REMAINING ANGLE BRACKETS TO THE T-BAR AND EACH STUD - 4' O.C.



Aerotech, Inc. 4215 Legion Drive, Mason, MI 48854-1036 USA  
 Toll-free: 800-227-2376 • Local: 517-676-7070 • Fax: 517-676-7078

INSTALLATION INSTRUCTIONS  
 FOR: T-BAR SUPPORT KIT (EC4012)

DATE 01-27-00	CHECKED BY RLD	REP. -
SCALE NTS	DRAWN BY DBB	JOB NO.
This plan is the exclusive property of Aerotech, Inc. and is authorized for use by Aerotech representatives and customers only. ©Copyright 2000, Aerotech, Inc.		DRAWING NO. QM1130